

GDC 073R126-000
Issue 1, November 1996

Installation and Operation

DataComm 721-T2

Warning

This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instruction manual, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device pursuant to CISPR-22 of FCC and international rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference, in which case the user at his own expense will be required to take whatever measures may be required to correct the interference. The user is cautioned that any changes or modifications not expressly approved by General DataComm void the user's authority to operate the equipment.

This digital apparatus does not exceed Class A limits for radio noise emissions from digital apparatus described in the Radio Interference Regulations of the Canadian Department of Communications.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la classe A prescrites dans le Règlement sur le brouillage radioélectrique édicté par le ministère des Communications du Canada.

Warranty

General DataComm warrants that its equipment is free from defects in materials and workmanship. The warranty period is one year from the date of shipment. GDC's sole obligation under its warranty is limited to the repair or replacement of the defective equipment provided it is returned to GDC, transportation prepaid, within a reasonable period. This warranty will not extend to equipment subjected to accident, misuse, or alterations or repair not made by GDC or authorized by GDC in writing. *The foregoing warranty is exclusive and in lieu of all other warranties, express or implied, including but not limited to, warranties of merchantability and fitness for purpose.*

Trademarks and Patents

General DataComm, the General DataComm logo and the following are trademarks of General DataComm, Inc in the United States and other countries: ACCULINE, ANALOOP, AUTOFRAME, BERT 901, DATACOMM SECURE-PAK, DATALOOP, DIGIDIAL, ENmacs, FASTPRO, FIRST RESPONSE, GDC, GDC APEX, GENERAL DATACOMM X-PRESS, GEN*NET, GEN*PAC, IMAGE*TMS, KILOMUX, LAN*TMS, MEGA*BRIDGE, MEGAMUX, MEGAMUX TMS, MEGANET, MEGASPLIT, MEGASWITCH, MEGAVIEW, NETCON, NETSWITCH, NMC, QUIKSHIPPERS, SERVI-CHECK, SERVI-SNAP, WINmacs.

ANALOOP and DATALOOP respectively are protected by U.S. patents 3,655,915 and 3,769,454. All other products or services mentioned in this document are identified by the trademarks, service marks, or product names as designated by the companies who market those products. Inquiries concerning such trademarks should be made directly to those companies.

HP OpenView is a trademark of the Hewlett-Packard Company.

Copyright

© 1996 General DataComm, Inc. All rights reserved.
P.O. Box 1299, Middlebury, Connecticut 06762-1299 U.S.A.

This publication and the software it describes contain proprietary and confidential information. No part of this document may be copied, photocopied, reproduced, translated or reduced to any electronic or machine-readable format without prior written permission of General Datacomm, Inc.

The information in this document is subject to change without notice. General DataComm assumes no responsibility for any damages arising from the use of this document, including but not limited to, lost revenue, lost data, claims by third parties, or other damages. If you have comments or suggestions concerning this manual, please write to Technical Publication Services or call 1-203-758-1811.

Table of Contents

Preface

1 System Description

Overview	1-1
Specifications	1-2
Applications	1-3
Configurations	1-5
Diagnostics/Network Management	1-9

2 Installation

Overview	2-1
Unpacking and Handling.....	2-1
Installation	2-1
Setting Hard Options.....	2-3
Electrical Connections.....	2-6
Preoperational Configuration	2-9

3 Operation

Overview	3-1
Front Panel	3-1
Setting Soft Options	3-3
Start-Up	3-3
Screen Organization	3-4
Operating Procedures	3-5
Main Menu	3-6
Diagnostic Menu	3-7
Configuration Menu	3-12
Network Management	3-20

4 Tests

Overview	4-1
Troubleshooting	4-1
Metallic Access Testing	4-1
Maintenance Menu	4-2
Loopbacks	4-3
Test Loopbacks - A Consideration.....	4-6
BER Test	4-6
Set RTC	4-9
Reset Statistic	4-10
HDSL Start-Up.....	4-10
Board Reset	4-11

Index

Antistatic Precautions

Electrostatic discharge (ESD) results from the buildup of static electricity and can cause computer components to fail. Electrostatic discharge occurs when a person whose body contains a static buildup touches a computer component.

The equipment may contain static-sensitive devices that are easily damaged and proper handling and grounding is essential. Use ESD precautionary measures when installing parts or cards and keep the parts and cards in antistatic packaging when not in use. If possible, use antistatic floorpads and workbench pads.

When handling components, or when setting switch options, always use an antistatic wrist strap connected to a grounded equipment frame or chassis. *If a wrist strap is not available, periodically touch an unpainted metal surface on the equipment.* Never use a conductive tool, like a screwdriver or a paper clip, to set switches.

Safety Guidelines

The following symbols are used when unsafe conditions exist or when potentially hazardous voltages are present:



Caution statements identify conditions or practices that can cause damage to the equipment or loss of data



Warning statements identify conditions or practices that can result in personal injury or loss of life.

Always use caution and common sense. *To reduce the risk of electrical shock, do not operate equipment with the cover removed.* Repairs must be performed by qualified service personnel only.

- Never install telephone jacks in a wet location unless the jack is designed for that location.
- Never touch uninsulated telephone wires or terminals unless the telephone line is disconnected at the network interface.
- Use caution when installing telephone lines and never install telephone wiring during an electrical storm.

FCC Part 68 Compliance

Connection of data communications equipment to the public telephone network is regulated by FCC Rules and Regulations. This equipment complies with Part 68 of these regulations which require all of the following.

For a single or multi-line equipment that connects to the telephone network via plug and jack, the plug and jack must comply with the FCC Part 68 rules. An FCC compliant telephone modular plug and telephone cord is provided with this equipment. This device is designed to be connected to the telephone network or premises wiring, using a compatible modular jack which is Part 68 compliant. See installation chapter for details.

If the unit causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. If advance notice is not practical, you will be notified as soon as possible and will be advised of your right to file a complaint with the FCC. The telephone company may change its communication facilities, equipment, operations and procedures where reasonably required for operation. If so, the telephone company will notify you in writing. All repairs or modifications to the equipment

must be performed by General DataComm. Any other repair or modification by a user voids the FCC registration and the warranty. To connect the DataComm 721-T2 to the public telephone network the customer is required to give the following information:

FCC Regulation number: AG6USA - 24105-DD-N
Telephone Company jack type: RJ48C/X

Digital devices only:

Facility Interface Codes: 04DU9-BN, DN, IKN, ISN
Service Order Code: 6.0Y

Canada DOC Notification

The Industry Canada label identifies certified equipment. This certification means that the equipment meets telecommunications network protective, operation and safety requirements as prescribed in the appropriate Terminal Equipment Technical Requirements document(s). The Department does not guarantee the equipment will operate to the user's satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be coordinated by a representative designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

Caution: Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as appropriate.

NOTICE: The Ringer Equivalence Number (REN) assigned to each terminal device provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all the devices does not exceed 5.

Deutschland

Installations Anweisungen: Installieren Sie die Telefonleitungen nicht während eines Gewitters. Installieren Sie die Telefonleitungen nicht in einem feuchten Raum, außer die Dose entspricht den Vorschriften für Feuchträume. Berühren Sie unisolierte Telefonleitungen oder Einrichtungen nicht, außer diese sind vom Telefonnetz getrennt.

Achtung: Es gibt keine durch den Benutzer zu wartende Teile im Gerät. Wartung darf nur durch qualifiziertes Personal erfolgen.

Preface

Scope

This manual describes how to install and configure a General DataComm 721-T1/T2 and explains how to monitor and manage network devices. This documentation is written for operators and installers, and assumes a working knowledge of data communications equipment.

Organization

This manual has four chapters. The information is arranged as follows:

- *Chapter 1 - System Description* introduces important concepts and features of the 721-T1/T2.
- *Chapter 2 - Installation* tells you how to install the 721-T1/T2. Only typical or fundamental applications are given because of the variety of specific customer system choices.
- *Chapter 3 - Operation* describes the front panels of the 721-T1/T2.
- *Chapter 4 - Tests* describes external tests.


The *Index* contains the 721-T1/T2 subject and page number.

Document Conventions

Level 1 paragraph headers introduce major topics.

Level 2 paragraph headers introduce subsections of major topics.

Level 3 paragraph headers introduce subsections of secondary topics.



Notes present special instructions, helpful hints or general rules.

Related Publications

The following documents have additional information that may be helpful when using this product:

- *Operating and Installation Instructions for DataComm Shelf* *GDC 010R310-000*

- *Operating and Installation Instructions for Universal System Shelf* GDC 010R380-000

GDC publication numbers (e.g., *GDC 073R126-000*) are used to track and order technical manuals. Publication numbers use the following format:

GDC NNNRnnn-000 or GDC NNNRnnn-Vnnn

NNN	identifies the product family (e.g. UAS)
R	denotes a technical publication
nnn	a number assigned by Technical Publications
000	identifies a hardware product and does not change
Vnnn	designates software version associated with a product, which may be updated periodically

The issue number on the title page changes only when a hardware manual is revised or when a manual is reprinted for some other reason; it does not automatically change when the software is updated. A new Software Version is always Issue 1. Other specialized publications such as Release Notes or Addenda may be available depending on the product.

Glossary of Terms

2B1Q Code

HDSL Line Code.

Address

A sequence of bits, a character, or a group of characters that identifies a network station, user, or application; used mainly for routing purposes.

BERT

Bit Error Rate Test, or tester.

A Binary Synchronous Communications protocol (BISYNC) that uses special characters to define the various fields of a message and for control functions. Typically used for transmission between a CPU and a CRT or batch-type processor. BISYNC accommodates a variety of transmission codes including ASCII, EBCDIC, and SBT (Six-Bit Transcode).

Bipolar

The predominant signaling method used for digital transmission services, such as DDS and T1, in which the signal carrying the binary value successively alternates between positive and negative polarities. Zero and one values are represented by the signal amplitude at either polarity, while no-value “spaces” are at zero amplitude; also, polar transmission.

Bit

A binary digit, the representation of a signal, wave, or state, as either a binary zero or a one.

Bit Error Rate (BER)

The percentage of received bits that are in error, relative to a specific amount of bits received; usually expressed as a number referenced to a power of 10; e.g., 1 in 10^5 .

Bps

Bits per second; basic unit of measure for serial data transmission capacity; also kbps (kilobits) for thousands of bits per second; Mbps (megabits), for millions of bits per second; Gbps (gigabits) for billions of bits per second; Tbps (terabits) for trillions of bits per second.

CSU

Channel Service Unit.

Data

Digitally represented information, which includes voice, text, facsimile, and video.

DDS

Dataphone digital service; private-line digital service offered intra-LATA by BOCs, inter-LATA by AT&T® Communications, with data rates typically at 2.4, 4.8, 9.6, and 56 kbps; now a part of the services listed by AT&T under the Accunet family of offerings.

Diagnostics

Tests used to detect malfunctions in a system or component.

DSU

Data Service Unit.

Ground

An electrical connection or common conductor that, at some point, connects to the earth.

HDSL

High-Bit Rate Digital Subscriber Line.

Interface

A shared boundary; a physical point of demarcation between two devices, where the electrical signals, connectors, timing, and handshaking are defined; the procedure, codes, and protocols that enable two entities to interact for the meaningful exchange of information.

Local Area Network

A type of high-speed data communications arrangement wherein all segments of the transmission medium (typically, coaxial cable, twisted-pair wire, or optical fiber) are under the control of the network operator.

Loopback

Diagnostic procedure used for transmission devices; a test message is sent to a device being tested, which is then sent back to the originator and compared with the original transmission; loopback testing may be within a locally attached device or conducted remotely over a communications circuit.

Modem

Modulator/demodulator; electronic device that enables digital data to be sent over (typically) analog transmission facilities.

Network

An interconnected group of nodes; a series of points, nodes, or stations connected by communications channels; the assembly of equipment through which connections are made between data stations.

Node

A point where one or more functional units interconnect transmission lines (ISO); a physical device that allows for the transmission of data within a network; an end-point of a link or a junction common to two or more links in a network (IBM SNA); typically includes host processors, communications controllers, cluster controllers, and terminals.

Self-Test

A diagnostic test mode to check modem performance in which the modem is disconnected from the telephone facility and its transmitter's output is connected to its receiver's input, permitting the looping of test messages (originated by the modem test circuitry) through the modem.

Terminal

A point in a network at which data can either enter or leave; a device, usually equipped with a keyboard, often with a display, capable of sending and receiving data over a communications link (IBM).

Transmission

The dispatching of a signal, message, or other form of intelligence by wire, radio, telegraphy, telephony, facsimile, or other means (ISO); a series of characters, messages or blocks, including control information and user data; the signaling of data over communications channels.

1 System Description

Overview

The 721-T1/T2 gives you local loop transmission for full and fractional T1 services, conforms to the ETSI HDSL standard, and operates on a two-wire metallic pair using High Bit-Rate Digital Subscriber Line (HDSL) technology. Using the 721-T2, a telephone company/carrier or an end user can transmit up to 1.544 Mbps on an unconditioned metallic cable. The 721-T1 is a one-loop version which allows data transmission of up to 768 Kbps. You can configure the 721-T1/T2 as a master (LTU) or as a slave (NTU). The 721-T1/T2 is designed to interconnect with other 721-T1/T2 units, the 701-T2, or with the 731-D1/D2. You can install the 721-T1/T2 in the DataComm shelf (16 per shelf) for either the carrier central office or customer premises applications.

You can also configure the 721-T1/T2 as a single loop unit, so that the unit can operate with a 721-T1 or a 731-D1 NTU as point-to-point.

Board dip-switches and/or jumpers let you configure and control the 721-T1/T2; or you can control it from an optional ASCII terminal or from GDC's UAS Network Management System.

Specifications

This page presents you detailed technical aspects of the 721-T1/T2.

Local Side	
Rate	1544 Kbps
Framing	SF or ESF per ATT Pub. 54016 or ESF per ANSI T1-403.
Interface	1544 Kbps DSX-1 or DS-1
Data Encoding	B8ZS or AMI
Transmission Line	
Rate	Dual duplex 392 Kbaud signaling rate, with 2B1Q line code (each loop)
Framing	HDSL framing per ETSI RTR/TM-03036.
Transmit Power	13.5 dBm (+ - 0.5 dBm)
Twisted pair, non-loaded metallic loops up to 4.0 Km at 0.4 mm. Meets performance specifications of ETSI RTR/TM-03036, Bellcore TA-NWT-001210.	
Test Features	
Local Loopback	Front panel switch or terminal screen selectable.
Remote Loop-back	Front panel switch or terminal screen selectable.
Self-Test	Front panel switch or terminal screen selectable.
Dimensions	
Dimensions (Stand-alone)	Height: 3.9 in. (99 mm) Width: 10.9 in. (277 mm) Depth: 12.5 in. (318 mm) Weight: 8.1 lb. (3.6 kg)
Electrical	
Power	7 Watts at card edge
Environmental	
Temperature Card Assembly Card Assembly Storage	Operation - 0 to 50 degrees Celsius Non-Operating -40 to +85 degrees Celsius
Humidity	5 to 95% non-condensing
Altitude	Operating - 0 to 10,000 feet Non-Operating - 0 to 40,000 feet

Applications

The DataComm 721-T1/T2 lets you connect to such equipment as:

Workstations	Data terminals
LAN bridges	Cluster controllers
Host mainframes	Mini-computers
Digital telephones	Telephone switches
Video terminals	Video conference stations
T1 multiplexers	Sub-rate multiplexers
VSAT terminals	Microwave equipment

GDC has designed the 721-T1/T2 to handle typical functions for operating a LTU (Line Terminating Unit) or NTU (Network Terminating Unit). Using the 721-T1/T2 you can connect any two devices like those listed above in a point-to-point link with inexpensive telephone wires. (See Figures 1-1 through 1-5).

Point-to-Point

Full T1

The 721-T2 can operate in one of several configurations. The first typical application is shown in *Figure 1-1*. You can connect the T1 input/output of the units directly to a T1 cross-connect, a Digital Cross-Connect System, or into a higher order multiplexer for inter-office transport. For full T1 service-provisioning applications, connect the master 701-T2 or 721-T2 to a slave 721-T2. Also, you can use the 721-T2 transport to extend 1.544 Mbps service within your place of business.




Figure 1-1 Full T1

Full T1 to Remote V.35

You can use a 721-T2 in conjunction with a 731-D2 to provide 1.536 Mbps in a V.35 interface at the customer's premises. See *Figure 1-2* below.




Figure 1-2 Full T1 to Slave V.35

T1 to Nx64K V.35

You can use the 721-T1/T2 to provide Nx64K data service to a customer's site from a central office location. When you use the 731-D1 remote unit in a single loop provisioning configuration, a V.35 Nx64 Kbps signal is available (up to 12x64 Kbps). When you use the 731-D2 remote unit in a two-loop configuration, a V.35 Nx64 Kbps signal is available at the customer's site (configurable up to 24x64 Kbps). See Figure 1-3.




Figure 1-3 T1 to Nx64K V.35

Point-to-Multipoint

HDSL Units at Two Locations

You can connect the 721-T2 to HDSL units at two different locations using the point-to-multipoint configuration. This is useful for combining customer's data into a single T1 interface, which then can be sent to the network for proper routing. See Figure 1-4.




Figure 1-4 Point-to-T1 Multipoint

The 721-T2 maps the DS0s or V.35 Nx64 Kbps from the individual customer sites into proper alignment in its DSX-1 frame. When you use 721-T1 units at the remote sites, up to 12 T1 time slots are available at each remote site.

When you use 731-D1 units at the remote sites, a V.35 Nx64 Kbps signal is available at each remote location (up to 12x64 Kbps). Chapter 3 — Operation describes in detail these time slot mapping functions. See Figure 1-5.





Figure 1-5 Point-to-V.35 Multipoint

Configurations


Figures 1-6 through 1-9 show typical system configurations.



Unit Type:	LTU	NTU
Enabled Loops:	2	2
Front Panel Enable:	Enabled	Enabled
T1 Interface:	DSX-1	DSX-1
Line Code:	B8ZS	B8ZS
Frame Mode:	ESF/ANSI	ESF/ANSI
Line PreEqualization:	0-133*	0-133*
Loopback Type:	Line	Line
AIS Loopdown:	Inhibit	Inhibit
Network Configuration	LTU	NTU
Application:	P2P	P2P
Loop 1 Start DS0:	N/A	N/A
Loop 1 Consecutive DS0:	N/A	N/A
Loop 2 Start DS0:	N/A	N/A
Loop 2 Consecutive DS0:	N/A	N/A

*Set line pre-equalization according to the T1 transmit line length of the application.


Figure 1-6 Point-to-Point Application



Unit Type:	LTU	NTU
Enabled Loops:	1	1
Application:		P2P
Front panel Enable:		Enabled
Tx Clock Mode		Looped
CTS Mode		On
Data Rate:		4 x 64 Kbps
V54 Rx Mode		Enabled
FP RL Mode:		V54
T1 Interface:	DSX-1	
Line Code:	B8ZS	
Frame Mode:	ESF/ANSI	
Line PreEqualization:	0-133*	
Loopback Type:	Line	
AIS Loopdown:	Inhibit	
 Network Configuration	 LTU	
Application:	P2P	
Loop 1 Start DS0:	1	
Loop 1 Consecutive DS0:	4	

*Set line pre-equalization according to the T1 transmit line length of the application.


Figure 1-7 Single Loop Nx64K Service



	LTU	Remote 1	Remote 2
Unit Type:	LTU	NTU	NTU
Enabled Loops:	2	1	1
T1 Interface:	DSX-1	DSX-1	DSX-1
Line Code:	B8ZS	B8ZS	B8ZS
Frame Mode:	ESF/ANSI	ESF/ANSI	ESF/ANSI
Line PreEqualization:	0-133*	0-133*	0-133*
Loopback Type:	Line	N/A	N/A
AIS Loopdown:	Inhibit	Inhibit	Inhibit
Network Configuration	LTU	Remote 1	Remote 2
Application:	P2MP	P2MP	P2MP
Loop 1 Start DS0:	1	1	13
Loop 1 Consecutive DS0:	12	12	10
Loop 2 Start DS0:	13	N/A	N/A
Loop 2 Consecutive DS0:	10	N/A	N/A

*Set line pre-equalization according to the T1 transmit line length of the application.

Figure 1-8 Point-to-Point MultiPoint - T1



		Remote 1	Remote 2
Unit Type:	LTU	NTU	NTU
Enabled Loops:	2	1	1
Application:	P2MP	P2MP	P2MP
Front Panel Enable:	N/A	Enabled	Enabled
T1 Interface:	DSX-1		
Line Code:	B8ZS		
Tx Clock Mode		Looped	Looped
Frame Mode:	ESF/ANSI		
CTS Mode:		On	On
Data Rate		12 x 64 Kbps	10 x 64 Kbps
V54 Rx Mode:		Enabled	Enabled
FP RL Mode:		V54	V54
Line PreEqualization:	0-133*		
Loopback Type:	Line		
AIS Loopdown:	Inhibit		
Network Configuration	LTU		
Application:	P2MP		
Loop 1 Start DS0:	1		
Loop 1 Consecutive DS0:	12		
Loop 2 Start DS0:	13		
Loop 2 Consecutive DS0:	10		

*Set line pre-equalization according to the T1 transmit line length of the application.

Figure 1-9 Point-to-Point MultiPoint - V.35

Diagnostics/Network Management

A front panel terminal interface jack (CTRL) gives you full access to the diagnostic and configuration controls via a terminal interface. This menu-driven interface provides loopback control, access to performance monitoring registers, and control of the configuration of the unit.

You can also use the 721-T1/T2 as a standalone unit as part of the Universal Access System (UAS) when connected at the far-end to a 701-T2. The UAS is a family of network managed metallic looped, transmission products. A shelf-mounted UAS family member works with a standalone unit located at the far end of the access loop. You can get full network management capability if you use the SpectraComm Manager (SCM) and its interface into an SNMP controller.

Table 1-1 Equipment List

Description	GDC Part Number
DataComm 721-T1 - 117v	073A320-011
DataComm 721-T1 - 220v	073A320-012
DataComm 721-T1 - 240v	073A320-014
DataComm 721-T2 - 117v	073A320-001
DataComm 721-T2 - 220v	073A320-002
DataComm 721-T2 - 240v	073A320-004
DataComm 721-T2 (rackmount)	073P320-001
Enclosure/Shelves	
DE Cover	010D500-003
Base Assembly, 721-T1/T2, 117 Vac	010B038-001
Base Assembly, 721-T1/T2, 220 Vac	010B134-015
Base Assembly, 721-T1/T2, 240 Vac	010B134-015
DataComm Shelf, DS-1, 117 Vac	010B015-001
DataComm Shelf, DS-5R, -48 Vdc redundant power supplies	010M011-001
DataComm Shelf, DS-5NR, -48 Vdc non-redundant power supply	010M011-002
DataComm Shelf, DS-6R, -48 Vdc redundant power supplies, NEBS-compliant dimensions	010M047-001
DataComm Shelf, DS-6NR, -48 Vdc non-redundant power supply, NEBS-compliant dimensions	010M047-002
Universal System Shelf USS-1-D, 117 Vac, domestic	010B080-001
Universal System Shelf USS-1-DC/NR, -48 Vdc, non-redundant power supply	010M040-001
Universal System Shelf USS -1-DC/R, -48 Vdc redundant power supply	010B040-002

Table 1-1 Equipment List (Cont.)

Cables	
Interface cable, RJ48C plug to 9-pin female (HDSL CTRL port-to-terminal)	027H250-010
Modular Adapter DB25 male-to-dual BNC connectors	209-036-009
Interface cable 50-pin Amp connector to six 8-position modular jacks. Each cable can support up to six cards.	024H608-002
Interface cable, RJ48C plug-to-plug (CSU network port to the T1 line for any housing except a DataComm Shelf) (10 to 50-foot lengths; 10-foot length included with stand-alone enclosure models)	022H024-XXX
Interface cable, RJ48C plug-to-15-pin male (CSU network port to the T1 line: a. Any housing except a DataComm Shelf b. Canadian installation only; or optional cascade port to DTE) (10 to 50-foot lengths)	022H022-XXX
Interface cable, RJ48C plug to 15-pin female (CPE port to the T1 line, for Canadian installation only) (10 to 125-foot lengths)	022H020-XXX
Interface cable, RJ48C plug-to-25-pin male (CPE port to multiplexer/DTE, any housing except a DataComm Shelf) (10 to 50-foot lengths)	027H218-XXX
Interface cable, RJ48C plug-to-plug (CSU network port to the T1 network interface or cascade to DTE--for DataComm Shelf housing only) (10 to 50-foot lengths)	022H026-XXX
Interface cable, RJ48C plug-to-terminal lugs (CSU network port to the T1 line for a DataComm Shelf housing only) (10 to 50-foot lengths)	022H025-XXX
Adapter, RJ48C plug-to-jack (CSU network port to the T1 network interface--for a DataComm Shelf housing only)	029H203-001
Front panel access test jack patch cable (male-to-male) (24 and 60-inch lengths)	830-005-XXX
Front panel access test jack patch cable Bantam-to-WECO 310 (4 feet)	830-021-S001
Bantam-to-WECO 310 adapter plug	209-026-S001

2 Installation

Overview

This chapter guides you through installing and using the DataComm 721-T1/T2 in your communications network. If this is your first experience using this unit, you may wish to review *Chapter 1 — System Description* to ensure that you understand the key features and how to install and integrate the 721-T1/T2 in your network.

Unpacking and Handling


Inspect the unit for damage; if you see any damage, notify the shipper immediately. Save the box and packing material so that you can use it to reship the unit, if necessary.

Installation

1. You may install the 721-T1/T2 in a standalone enclosure or in a DataComm Shelf. All electrical connections are made through the backplane interface.
2. Place the unit in a ventilated area where the ambient temperature does not exceed 122°F (50°C).
3. Do not install the unit directly above equipment that generates a large amount of heat (such as power supplies).

Standalone Installation

1. To remove the component cards from the standalone base, disconnect the power supply connector from J1 mounted at the rear center of the base card.
2. When you reinstall the component cards to the base, reinstall the connector at J1. *See Figure 2-1.*
3. Attach the appropriate power cord to the rear panel IEC connector of the wall receptacle (depending on the base assembly you ordered).
4. Be sure that the unit is powered by the same ac source as the equipment that you are interfacing with the unit. This prevents large circulating currents caused by differences in ground potential.
5. If you cannot determine whether the equipment is powered by the same ac source, then verify that a potential difference of less than 0.25 V rms exists between the grounding circuits of the respective power outlets.

**Caution:**

Disconnect power cable and phone connections before removing cover.

- ① With front of unit facing left, turn screw to release cover.
- ② Lift right end of cover upward.
- ③ Slide cover left with an upward motion.

When reinstalling cover, top edge of rear panel must sit between the two ridges on underside of cover.

Figure 2-1 Standalone Cover Removal Procedure

Shelf

To install the DataComm Shelf, refer to *Operating and Installation Instructions for DataComm Shelf*, GDC Publication Number 010R310-000.



Be sure to install shelves and power supplies as described in the DataComm Shelf manual. Failure to do so may result in overheating and subsequent power supply shutdown.

Mounted in a DataComm Shelf (DS-1, DS-5, or DS-6), the 721-T1 and 721-T2 support as many as 16 units. You may install these units in any unoccupied slot in the shelf. Install the unit in the shelf as follows:

1. Insert card in top and bottom slot guides with the GDC logo on top, and carefully slide the assembly into the slot until it stops at the rear connectors.
2. Push the front panel with both hands until the assembly mates with the rear connectors.


The Universal System Shelf (USS-1) accommodates sixteen 721s and uses harness cards and backplanes configured to occupy one card slot in the shelf for each unit. Each backplane assembly is keyed by a tab located at the bottom of the harness card. This tab mates with a slot that is part of the shelf and keeps backplanes from being inserted incorrectly in the shelf.

Install the 721 in the USS-1 shelf:

1. Loosen backplane screws and install the plug-in card from the front of the shelf by sliding it into the card guides.
2. Seat firmly into the mating connectors on the backplane using both hands.
3. Tighten the backplane screws. This accurately aligns the cards in the card guides and the mating connectors on the backplane. Furthermore, this lets you take out the cards easily.
4. Plug in the four-pin cable harness on the backplane adapter to the shelf power connector located directly above the backplane adapter.

Setting Hard Options

Setting the hard options on the cards means adjusting configuration Switches S1 and S2 and jumpers to match your network operation. *Table 2-1* explains the functions of the switches and jumpers, and *Figure 2-2* shows their locations. You can choose the hard configuration by Switch S2-1.



The microprocessor in the UAS 721-T1/T2 reads the switch settings only when you first power up. If you change the settings while the power is on, you must turn the power off and power up again for the new settings to take effect. Soft options that are changed while the power is on do not require a power cycle. Soft options are stored in non-volatile memory and do not need to be reset after a power interruption.

You need to make these adjustments only once when first installing the unit. You don't have to repeat this procedure, unless you change your network or connect a different device to a data channel. Factory default is off for all switches.

Table 2-1 Option Selection

Switches	Description																														
S1-1, S1-2 (FRM0, FRM1)	T1 Framing FRM0=Off, FRM1=Off: ESF/ANSI FRM0=Off, FRM1=On: ESF/54016 FRM0=On, FRM1=Off: SF FRM0=On, FRM1=On: UNFRAMED																														
S1-3 (B8ZS/AMI)	Selects T1 line coding. AMI (Alternate Mark Inversion) or B8ZS (Bit 8 zero suppression) Off - B8ZS On - AMI																														
S1-4 (DS-1/DSX-1)	Selects T1 interface. Off - DS-1 On - DSX-1																														
S1-5, S1-6, S1-7 (TXLN0, TXLN1, TXLN2)	Selects T1 transmit line build-out or pre-equalization. The switches are: <table border="1"> <thead> <tr> <th><u>S1-5</u></th> <th><u>S1-6</u></th> <th><u>S1-7</u></th> <th><u>DSX-1</u></th> <th><u>DS-1</u></th> </tr> </thead> <tbody> <tr> <td>Off</td> <td>Off</td> <td>Off</td> <td>0-133 ft.</td> <td>0 dB</td> </tr> <tr> <td>On</td> <td>Off</td> <td>Off</td> <td>133-266 ft.</td> <td>-7.5 dB</td> </tr> <tr> <td>Off</td> <td>On</td> <td>Off</td> <td>266-399 ft.</td> <td>-15 dB</td> </tr> <tr> <td>On</td> <td>On</td> <td>Off</td> <td>399-533 ft.</td> <td>-22.5 dB</td> </tr> <tr> <td>Off</td> <td>Off</td> <td>On</td> <td>533-655 ft.</td> <td>---</td> </tr> </tbody> </table>	<u>S1-5</u>	<u>S1-6</u>	<u>S1-7</u>	<u>DSX-1</u>	<u>DS-1</u>	Off	Off	Off	0-133 ft.	0 dB	On	Off	Off	133-266 ft.	-7.5 dB	Off	On	Off	266-399 ft.	-15 dB	On	On	Off	399-533 ft.	-22.5 dB	Off	Off	On	533-655 ft.	---
<u>S1-5</u>	<u>S1-6</u>	<u>S1-7</u>	<u>DSX-1</u>	<u>DS-1</u>																											
Off	Off	Off	0-133 ft.	0 dB																											
On	Off	Off	133-266 ft.	-7.5 dB																											
Off	On	Off	266-399 ft.	-15 dB																											
On	On	Off	399-533 ft.	-22.5 dB																											
Off	Off	On	533-655 ft.	---																											
S1-8 (SPARE)	Future use.																														
S2-1 (SFT/HRD)	Selects either soft or hard configuration mode. Off - Configuration is restored from non-volatile memory. On - Configuration is obtained from basecard switches.																														
S2-2 (NTU/LTU)	Selects whether unit is configured as a line terminating unit (LTU) or network terminating unit (NTU). Off - NTU On - LTU																														
S2-3 (2LP/1LP)	Selects the number of enabled loops. Off - Two loops enabled On - One loop enabled																														
S2-4 (FPEN/DIS)	Selects front panel switch operation. Off: Front panel LL, RL, and ST switches are operational. On: Front panel LL, RL, and ST switches are disabled.																														
S2-5, S2-6 (TMG0, TMG1)	T1 Timing: Clock Source: TMG0=Off, TMG1=Off: Looped - clocked derived from T1 received signal. TMG0=Off, TMG1=On: Internal - 721-T1/T2 generates clock source TMG0=On, TMG1=On: External - station clock from connector P2, Pins 11 and 24, or J4 Pins 3 and 6.																														
S2-7 (SPARE)	Future use.																														
S2-8 (SPARE)	Future use.																														
Jumpers	Description																														
X4	Select 0 for common signal and chassis grounds. Select 100 for grounds isolated by 100 Ohms. Select Open for isolated signal and chassis grounds.																														
X5	For T1 Span Loop pass-through. Pin 1 must be shorted to Pin 2 with Pin 3 open.																														
X6, X12	These must be shorted. Removal with remote power option installed enables sealing current remote power feeding.																														
X7, X8	Connects HDSL Loop 2 to RJ48C/X Jack J3 when shorted.																														
X10, X11	Connects HDSL Loop 1 to RJ48C/X Jack J3 when shorted.																														
X9 (JTAG)	For factory use. (Install jumper for normal operation.)																														




Figure 2-2 Option Switch and Jumper Locations

Electrical Connections

The following figures show connections for power and communications lines to the UAS 721-T1/T2.




Figure 2-3 DE-7 Standalone Enclosure Rear Panel




Figure 2-4 DE-23E Enclosure




Figure 2-5 DataComm and Universal System Shelf Rear Panel Connections

Below is *Table 2-2*, showing you the RJ48C/X interface pin-outs for the rear panel DataComm shelf. Following this table is *Figure 2-6*, which depicts the RJ48 C/X Jack.

Table 2-2 RJ48C/X 8-Position Interface Pin-Outs

Connector Pin Assignments T1 Connectors		
Pin No.	RJ48C/X	Color
1	T1-RX-R	Blue
2	T1-RX-T	Orange
3	EXT-CK-POS	Black
4	T1-TX-R	Red
5	T1-TX-T	Green
6	EXT-CK-NEG	Yellow
7		Brown
8		Slate
HDSL Connector		
1	HDSL2-R	Blue
2	HDSL2-T	Orange
3		Black
4	HDSL1-R	Red
5	HDSL1-T	Green
6		Yellow
7		Brown
8		Slate

**Figure 2-6** RJ48 C/X Jack for the T1 Line

Preoperational Configuration

Setup (Hard)

Configure the unit as follows:

1. Verify that Jumpers X7, X8, X9, X10, and X11 are installed.
2. Verify that the card is configured as an LTU or NTU based upon *Table 2-1*.
3. Set the remaining switches and jumpers according to *Table 2-1* and *Figure 2-2*.

If S2-1 is placed in the SOFT configuration position, all other switch settings are ignored, and the unit must be configured via the optional terminal screen. Refer to the following section: *Setup (Soft)*.

4. Connect the T1 line and HDSL loops to the network connectors on the rear panel.
5. Insert the card (NTU or LTU) into a previously powered-up DataComm Shelf, or plug in power to the standalone enclosure.

The card automatically performs internal self-tests. If one of these tests fails, the front panel ALM LED blinks.

6. After going through the self-tests, the HDSL loops (LTU and NTU) initiate start-up and the HDSL ES green LEDs blink.

The start-up generally last less than 30 seconds, but may take up to 3 minutes. When complete, the HDSL NORM LEDs are Off. If not, the start-up failed. The two cards automatically initiate a new start-up procedure.

During this time the ALM light blinks until all T1 and HDSL status indicators clear.

7. When T1 data transfer occurs, the T1 NORM LED is On and the ER LED is Off. If this does not happen, refer to the troubleshooting procedure in *Chapter 4 Tests*.

Setup (Soft)

1. Verify that Jumpers X7, X8, X9, X10, and X11 are installed.
2. Verify that Switch S2-1 is in the SFT position.
3. Connect the T1 line and HDSL loops to the network connectors on the rear panel.
4. Insert the card (NTU or LTU) into a previously powered-up DataComm Shelf, or plug in power to the standalone enclosure.

The card automatically performs internal self-tests. If one of these tests fails, the front panel ALM LED blinks.

5. When Switch S2-1 is in the SFT position on power-up, configuration parameters are initially set to the last configuration settings present when the unit was last powered On (or factory defaults, if unit is new). When Switch S2-1 is in the HRD position, initial configuration settings are obtained from Switches S2-1 through S1-8, and Switches S1-1 through S1-8.
6. After going through the self-tests, the HDSL loops (LTU and NTU) initiate start-up and the HDSL ES green LEDs blink.

The start-up generally last less than 30 seconds, but may take up to 3 minutes. When complete, the HDSL NORM LEDs are Off. If not, the start-up failed. The two cards automatically initiate a new start-up procedure.

During this time the ALM light blinks until all T1 and HDSL status indicators clear.

7. When T1 data transfer occurs, the T1 NORM LED is On and the ER LED is Off. If this does not happen, refer to the troubleshooting procedure in *Chapter 4 Tests*.
8. Connect an ASCII terminal the CTRL connector on the front panel and proceed to *Chapter 3, Operation*, to access the 721-T1/T2.
9. To view the power On test results on the terminal, go to the View H/S Config option on the terminal. (*Refer to Setting Soft Options in Chapter 3 - Operation.*)
10. Verify the configuration of the T1 interface parameters. (*Refer to Setting Soft Options in Chapter 3 - Operation.*)

3 Operation

Overview

Figure 3-1 presents the DataComm 721-T1/T2 front panels and explains each control and indicator. You may check the operation of the unit by monitoring the front panel indicators and using the test procedures found in *Chapter 4*.

By setting the options and the communication line properly, you need no additional operator commands. The units are transparent to your network and automatically communicate with each other and with your connected network devices.

Front Panel

You can monitor three data streams on the front panel, represented by these LED indicators:

HDSL loop 1 input	- ES LP1 or NORM LP1
HDSL loop 2 input	- ES LP2 or NORM LP2 (721-T2 only)
Incoming T1 signal	- T1 ER or T1 NORM

Each LED indicator can be in one of three states: On, blinking, or Off. Blinking is at a 2-Hz rate. *Table 3-1* summarizes these indicators.

Table 3-1 Front Panel Indicators

HDSL Indicators		
ES Indicators	NORM Indicators	Indication
Off	On	Normal operation
On	Off	LOS/LOSW
On (for 0.5 sec.)	On	ES - Errored second
On	Blink	Start-up in progress. No response received from mating unit.
Off	Blink	Start-up in progress. Signal from mating unit has been received.
T1 Indicators		
ER Indicator	NORM Indicator	Indication
Off	On	Normal operation
On	Off	LOS, OOF, or AIS
Blink	On	ER - Errored seconds
Other Indicators		
ON	Lit when +5V is applied to the card	
ALM	Indicates a major alarm. If a failure is detected during self-test, this LED blinks. It also blinks upon the detection of LOS, LOSW, or UAS on any HDSL loop.	
TM	This LED is on during one of the following conditions: <ul style="list-style-type: none"> • Loopback is activated at the local unit • Loopback is activated at the remote unit • The BER meter has been activated This LED blinks when a BER test is in progress and bit errors are present.	




Figure 3-1 Front Panels of the 721-T1/T2

Setting Soft Options

You can use an ASCII terminal equipped with an EIA/TIA-232-E communication interface to control the 721-T1/T2. You connect the terminal to the control (CTRL) jack on the front panel. To end an ongoing management session, disconnect the terminal from the 721-T1/T2.

Terminal Requirements

You can use any standard ASCII terminal (VT100 or ANSI terminal or personal computer emulating an ASCII terminal) equipped with an EIA/TIA-232-E communication interface to control unit operation. Screens depicted in the remaining sections of this chapter were derived by plugging the Comm port of a pc (using any terminal emulator program) into the CTRL jack on the front panel of the unit.

Set the terminal communications parameters as follows:

- Data Rate = 9600 bps
- Character Format = 1 start bit / 8 data bits / no parity / 1 stop bit

The software to run the supervision program is contained in the 721-T1/T2.

Control Port Characteristics

The control port is terminated in an RJ45 connector, designated as CTRL on the front panel, and is wired as shown below:

Pin	Function
1, 2, 3	Not connected
4	Ground
5	Transmit output (RXD of terminal)
6	Receive input (TXD of terminal)
7, 8	Shorted internally

Start-Up

As soon as you connect the terminal cable to the CTRL port of an operating 721-T1/T2, you automatically start a management session. Upon power-up, the 721-T1/T2 sends the opening screen, shown in *Figure 3-2*, followed by the main menu.




Figure 3-2 Opening Screen

Screen Organization

The screen includes the areas described in *Table 3-2*.

Table 3-2 Terminal Screen Organization

Header	Located at the top of the screen; displays the: <ul style="list-style-type: none"> • GDC abbreviation and the full manufacturer's name • equipment make • current operating mode (LTU or NTU) • data and time sent by the 721-T1/T2.
Status Line	Located below the header; includes two main fields displaying the status of the various 721-T1/T2 alarms. An active alarm indicator is displayed in reverse video.
T1 alarms field	Includes the following indications: LOS - Loss of input signal on the T1 interface. RAI - Reception of remote alarm indication via the T1 interface. AIS - Reception of unframed all ones on the T1 interface. UAS - Unavailable seconds recorded by the T1 interface. R-LOS - Reception of remote loss-of-T1 signal report via the HDSL interface. OOF - Out of frame on the T1 interface.
Loop alarms Field	Divided into sub-fields, one for each loop; includes the following indications: LOS - Loss of input signal on the corresponding loop. UAS - Unavailable seconds threshold for the corresponding loop is being exceeded. LOSW - Loss of synchronization word on the corresponding loop. MAJ - Incoming bit error rate exceeds selected major alarm threshold. MIN - Incoming bit error rate exceeds selected minor alarm threshold.
Work Area	Displays the menu and dialog boxes.
Active Keys Area	Constantly updated to show keys and combinations available on the current screen.

Operating Procedures

The following procedures apply to all the operations that you do on the ASCII terminal.

Menu Selection

You can select a Menu item in two ways:

1. Move the selected block to the desired item by means of the arrows, then press the Enter key.
2. Type the number appearing to the side of the menu item.

Either action opens the submenu or dialog box used to carry out the selected operation.

Field Navigation

To move forward among the fields of a dialog box, press the Down arrow key. To move backward, press the Up arrow key.

Field Editing

You can modify the values displayed in the screen fields as follows:

1. Bring the cursor to the desired field, then press Enter to display an option menu with the available values.
2. Highlight the desired value, then press Enter to select the new value and close the option menu.
3. For free-text fields, bring the cursor to the desired field, then type in the desired value.

You can use the Backspace and Delete keys to make changes or correct errors. When done, press Enter.

Restoring Default Values

You can replace the current screen values with the 721-T1/T2 default values by pressing Ctrl-D (Ctrl-D means hold down the control key and press D).

Saving Values

To save new parameter values entered in dialog boxes, press Ctrl-W. These parameters are stored in non-volatile memory for use upon the next unit power-up in SOFT Config mode (S34-1 switch is set to SFT).

Quitting without Saving

To quit without saving the new parameter values entered in a field, press Esc. You can also press Esc as necessary to close any open submenus and to return to the main menu.

Refresh

You may refresh the screen at any time by typing Ctrl-R.

Main Menu

The Main Menu is displayed in *Figure 3-3*. The menu includes three options, described in the following sections.




Figure 3-3 Main Menu

Diagnostics

Apply this option to display diagnostic information and to activate or control diagnostic functions, as follows:

- Display performance statistics collected on the T1 interface and on each of the HDSL loops.
- Display HDSL loop status information, technical data on loop performance, HDSL loop noise margins, optional gain settings, and loop characteristics.
- Cancel the start-up process.

You can activate loopbacks through the Maintenance option of the Main Menu.

Configuration

Apply this option to configure the T1 and HDSL interface parameters, as follows:

- Modify the HDSL loop operating mode and front panel pushbuttons.
- Display and modify the T1 line code, T1 framing mode, line build-out, inband loopback parameters, and timing source.
- Set/modify the network circuit configuration and time slot routing over the HDSL loops.
- Display system hardware and software data and 721-T1/T2 self-test results.

Maintenance

Apply this option to do maintenance activities:

- Enable both local and remote system loopbacks.
- Test system performance using the internal 721-T1/T2 BER meter.
- Set the real-time clock of the 721-T1/T2.
- Reset the 721-T1/T2 statistics counters.
- Manually initiate the start-up process.
- Reset the 721-T1/T2. (Simulate a power-up.)

Refer to *Chapter 4 - Tests*.

Diagnostic Menu

Selecting the Diagnostics option from the Main Menu displays the Diagnostics menu, shown in *Figure 3-4*. Use this menu to display diagnostic information and to activate diagnostic functions.




Figure 3-4 Diagnostics Menu

The functions available from the diagnostics menu are as follows:

- T1 Monitoring
- HDSL Monitoring
- HDSL Status
- Cancel Startup

T1 Monitoring

This menu item displays the 24-hour performance statistic data collected on the T1 interface. *Figure 3-5* depicts a typical T1 monitoring screen.




Figure 3-5 T1 Monitoring Screen

The screen includes the fields described in *Table 3-3*.

Table 3-3 T1 Monitoring Screen Fields

Valid Intervals	Displays the number of valid 15-minute intervals within the current 24-hour interval. The range is 0 to 96.
Interval Time	Displays the elapsed time in seconds from the beginning of the current 15-minute interval. The range is 0 to 900.
ES	Displays the number of errored seconds in the current 15-minute interval.
Last 24 Hr. ES	Displays the number of errored seconds in the last 24-hour interval.
UAS	Displays the number of unavailable seconds in the current 15-minute interval.
Last 24 Hr. UAS	Displays the number of unavailable seconds in the last 24-hour interval.
SES	Displays the number of severely errored seconds in the current 15-minute interval.
Last 24 Hr. SES	Displays the number of severely errored seconds in the last 24-hour interval.
BES	Displays the number of burst errored seconds in the current 15-minute interval.
Last 24 Hr. BES	Displays the number of burst errored seconds the last 24-hour interval.
LOFC	Displays the number of frame loss events in the current 15-minute interval.
Last 24 Hr. LOFC	Displays the number of frame loss events in the last 24-hour interval.
CSS	Displays the number of controlled frame slip seconds in the current 15-minute interval.
Last 24 Hr. CSS	Displays the number of controlled frame slip seconds in the last 24-hour interval.

T1 Monitoring Operation

The T1 monitoring screen displays data for the current 15-minute interval.

After viewing the data for the current 15-minute interval, you can display the other 95 intervals in the current 24-hour interval by pressing any key, except the R, A, and the ESC keys. The display is cyclic, that is, the current interval is displayed again after the 95th interval.

To reset the T1 statistics counters, type R. All the displayed values are reset to 0. To exit and return to the Diagnostics menu, press Esc.

If the 721-T1/T2 is configured for ESF/ANSI framing mode, then T1 ANSI statistics are available for display. To display ANSI statistics (as shown in Figure 3-6), type A while in the T1 monitoring screen. This screen includes the fields described in Table 3-4.




Figure 3-6 T1 ANSI Monitoring Screen

Table 3-4 T1 ANSI Monitor Fields

CRC	Displays the number of CRC errors in the one-second interval.
BPV	Displays Yes if any bipolar violations occurred in the one-second interval.
SEFE	Displays Yes if any severely errored framing events occurred in the one-second interval.
PLB	Displays Yes if any payload loopback events occurred in the one-second interval.
FE	Displays Yes if any frame errors occurred in the one-second interval.
CSS	Displays Yes if any controlled frame slips occurred in the one-second interval.

ANSI Statistics Operation

To display ANSI statistics for inbound data, type I. You may again view ANSI statistics for outbound data by typing O.

To return to the original 54016 T1 monitor display, type 5.

To exit and return to the diagnostics menu, press Esc.

HDSL Monitoring

The HDSL Monitoring screen displays 24-hour performance statistics on the HDSL loops. A typical screen is shown in Figure 3-7.




Figure 3-7 HDSL Monitoring Screen

The HDSL Monitoring screen is similar to the T1 Monitoring screen. The main difference is the addition of a loop field that identifies the HDSL loop described by the screen, and the inclusion of a FEBE field. *Table 3-5* describes the fields on the HDSL Monitoring screen.

Table 3-5 HDSL Monitoring Screen Fields

ES	Displays the number of errored seconds in the current 15-minute interval.
Last 24 Hr . ES	Displays the number of errored seconds in the last 24-hour interval.
UAS	Displays the number of unavailable seconds in the current 15-minute interval.
Last 24 Hr . UAS	Displays the number of unavailable seconds in the last 24-hour interval.
SES	Displays the number of severely errored seconds in the current 15-minute interval.
Last 24 Hr . SES	Displays the number of severely errored seconds in the last 24-hour interval.
FEBE	Displays the number of far-end block errors reported by the remote HDSL unit in the current 15 minute interval.
Last 24 Hr . FEBE	Displays the number of far-end block errors in the last 24-hour interval.

HDSL Monitoring Screen Operation

To display the HDSL monitoring screen, select Item 2 on the Diagnostics menu. The screen displays the data collected for Loop 1 in the current 15-minute interval.

To select another loop, type its number: 1 or 2.

To display the other 95 intervals within the current 24-hour period, press any key except 1, 2, 3, R, and Esc. The display is cyclic; that is, the current interval is displayed again after the 95th interval.

To reset the HDSL statistics counters, type R. All the displayed values are reset to 0.

To exit and return to the diagnostics menu, press Esc.

HDSL Status

This option displays the HDSL Status screen, which shows you diagnostic information and technical data on HDSL loop performance. A typical screen is shown in *Figure 3-8*.




Figure 3-8 HDSL Status Screen

Table 3-6 describes the fields on the HDSL Status screen.

Table 3-6 HDSL Status Screen Fields

Loops Exchange	Indicates whether the HDSL loops carrying the T1 traffic are correctly connected or have been interchanged by error. This information is available only when the two 721-T1/T2 units connected in a link can exchange information, and is not applicable if unit is configured as an LTU. If the Loops Exchange indicates Yes, then the swapped wires must be corrected.
Loop 1 TIP/RING Reversal	Indicates whether the two conductors of HDSL Loop 1 are correctly connected or have been interchanged by error. This information is available only when the two HDSL units connected in a link can exchange information, and is not applicable if unit is configured as an LTU. If Tip/Ring Reversal indicates Yes the 721-T1/T2 series will automatically detect and recover from this condition.
Loop 2 TIP/RING Reversal	Indicates whether the two conductors of HDSL Loop 2 are correctly connected or have been interchanged by error. This information is available only when the two HDSL units connected in a link can exchange information, and is not applicable if unit is configured as an LTU. If Tip/Ring Reversal indicates Yes the 721-T1/T2 series will automatically detect and recover from this condition.
Noise Margin	Displays the noise margin, in dB, measured by the signal processing circuits of the 721-T1/T2. Separate values are provided for each HDSL loop.
Pulse Attenuation	Displays the pulse attenuation, in dB, measured by the signal processing circuits of the 721-T1/T2. Separate values are provided for each HDSL loop.

HDSL Status Screen Operation

To display the HDSL Status screen, select Item 3 on the Diagnostics menu. After viewing the data, press **ESC** to exit and return to the Diagnostics menu.

Cancel Start-up

The Cancel Startup option is used to cancel the start-up process which is carried out by the 721-T1/T2 upon link initialization and whenever the synchronization between the two 721-T1/T2 units connected in a link is lost. To instruct the 721-T1/T2 to stop performing the start-up process, select Item 4 from the Diagnostics menu.

Configuration Menu

Use the Configuration menu to configure the T1 and the HDSL loop parameters.

To open the Configuration menu, select Item 2 on the Main Menu. *Figure 3-9* depicts the Configuration menu.




Figure 3-9 Configuration Menu

The functions available from the Configuration menu are as follows:

- Unit Configuration
- Interface Configuration
- Network Configuration
- View H/S Configuration

Unit Configuration

The Unit Configuration option displays the Unit Configuration screen, showing the HDSL configuration parameters of the 721-T1/T2. A typical screen is shown in *Figure 3-10*.




Figure 3-10 Unit Configuration Screen

The screen includes five fields that you use to select the operating mode of the 721-T1/T2 on the HDSL loops side, alarm thresholds, and the control of the front panel pushbuttons (See Table 3-7 below):

- Unit Type
- Enabled Loops
- Major Alarm Threshold
- Minor Alarm Threshold
- Front Panel Enable

Table 3-7 Unit Configuration Screen Fields

Unit Type	LTU - Line Terminating Unit NTU - Network Terminating Unit
Enabled Loops	1 or 2 loops available with the DC721.
Maj Alm Thres	Programmable threshold from 10^{-4} to 10^{-8} for determining incoming line bit error rate. Set to a higher threshold than MIN ALM THRES to indicate conditions of major line problems.
Min Alm Thres	Programmable threshold from 10^{-4} to 10^{-8} for determining incoming line bit error rate. Set to a lower threshold than MAJ ALM THRES to indicate conditions of minor line problems.
Front Panel EN	Enabled; allows RL, LL, and ST diagnostics from the front panel Disabled; prohibits RL, LL, and ST diagnostics from the front panel

Unit Configuration Screen Operation

To change the current value of a field, use the following procedure:

1. Move the selection block to the desired field and press Enter.

An option menu appears with the available options.

2. Highlight the desired option, and press `Enter`.

The option menu closes, and the new selection appears in the corresponding field.

3. To reset the selected fields to the default values, press `Ctrl-D`. Default values are shown in *Figure 3-10*.
4. To save changes, press `Ctrl-W`.
5. To quit and cancel the changes made in this screen, press `Esc`.
6. To exit and return to the Configuration menu, press `Esc`.

Interface Configuration

The Interface Configuration option displays the Interface Configuration screen, showing the T1 configuration parameters of the 721-T1/T2. A typical screen is shown in *Figure 3-11*.




Figure 3-11 Interface Configuration Screen

The screen includes the fields described in *Table 3-8*.

Table 3-8 Interface Configuration Screen Fields

T1 Interface	Displays the current T1 interface, DSX-1 or DS-1
Line Code	Displays the current T1 line code used by the 721-T1/T2: AMI - The T1 line coding is Alternate Mark Inversion. B8ZS - The T1 line coding is Bit 8 zero suppression.
Frame Mode	Displays the current framing mode of the 721-T1/T2 with respect to the T1 interface: ESF/ANSI - The 721-T1/T2 uses ESF framing with facility data link according to ANSI T1.403. ESF/54016 - The 721-T1/T2 uses ESF framing with facility data link according to ATT Pub. 54016. SF - 721-T1/T2 uses SF framing. UNFRAMED - 721-T1/T2 utilizes an unframed 1.544 Mbps data stream.
TX PreEqualization:	Displays the current transmit signal conditioning tailored for the transmit line length. This option is available only when T1 interface is DSX-1. Choose from 0-133, 133-266, 266-399, 399-533, or 533-655 ft.
TX Line Build-out	Displays the current transmit signal conditioning when the T1 interface is DS-1. Choose from 0db, -7.5 db, -15 db, or -22.5 db.
Loopback Type	Displays the current type of loopback (line, payload, or inhibit) which is activated when the 721-T1/T2 receives an inband loopback request at the T1 interface.
AIS Loopdown	Displays the time requirement of consecutive ones received on the T1 interface which causes an inband loopback to terminate. This feature can be inhibited.
Timing Source	Displays the current source of timing clock for T1 transmit data. Choose from Loop (timing recovered from T1 signal), External (from station clock), or Internal (721-T1/T2 generates timing).

Interface Configuration Operation

To change the current value of a field, use the following procedure:

1. Move the selection block to the desired field and press `Enter`.

An option menu appears with the available options.

2. Highlight the desired option, and press `Enter`.

The option menu closes, and the new selection appears in the corresponding field.

3. To reset the selected fields to the default values, press `Ctrl-D`. Default values are shown in *Figure 3-11*.
4. To save changes, press `Ctrl-W`.
5. To quit and cancel the changes made in this screen, press `Esc`.
6. To exit and return to the Configuration menu, press `Esc`.

Network Configuration

The Network Configuration option displays the Network Configuration screen, showing the network topology and time slot routing options of the 721-T1/T2. A typical screen is shown in *Figure 3-12*.




Figure 3-12 Network Configuration Screen

Operation

1. To display the Network configuration screen, select Item 3 on the configuration menu.

This screen includes the following fields:

- | | |
|------------------|--|
| Application | Determines whether the unit is being used in Point-to-Point (P2P) or in a Point-to-Multi-Point (P2MP) network configuration. |
| Loop | Selects the HDSL loop that the Start DS0 and Consecutive DS0 options are being configured for. Not used for P2P mode. |
| Start DS0: | For P2MP mode, selects the starting DS0 of the contiguous block of DS0s being provisioned for a particular Loop. Not used for P2P, mode, except in a single loop P2P network configuration. |
| Consecutive DS0s | For P2MP mode, selects the number of DS0s in the contiguous block of DS0s being provisioned for a particular Loop. Not used for P2P mode, except in a single loop P2P network configuration. |
2. To change the current value of application, highlight the desired option and press **Enter**. This displays an option menu with the available options P2P and P2MP.
 3. Highlight the desired option and press **Enter**. The option menu closes and the new selection appears on the screen.
 4. To change the current value of the loop, highlight the desired option and press the (+) key or the space bar to increment, or the (-) key to decrement the loop number to the desired loop. This is available for P2MP mode only, and in P2P mode, this option should be left at 1. The loop number increments to the maximum number specified by Enabled Loops in the Unit Config screen.
 5. To change the current value of Start DS0, highlight the desired option and press the (+) key or the space bar to increment, or the (-) key to decrement the starting location of the first time slot allocated for the selected loop. This is available for P2MP mode only, and in P2P mode, this option should be left at 1.

6. To change the current value of consecutive DS0s, highlight the desired option and press the (+) key or the space bar to increment, or the (-) key to decrement the number of consecutive time slots allocated for the selected loop. This is available for P2MP mode only, and in P2P mode, this option should be left at 1.
7. To save the changes made in this screen press CTRL-W.
8. To quit and cancel the changes made in this screen, press ESC.
9. To return to the configuration menu without saving, press ESC.

Point-to-Point Data Routing

The T1 payload is distributed along the HDSL loops with consecutive DS0s placed in ascending order in the HDSL loops as shown in *Table 3-9*. When a 721-T2 or 701-T2 unit is remote, the T1 payload is recombined at the remote end such that the full T1 frame is exactly reconstructed.

When the 721-T2 is used with a 731-D2 remote unit, and two loops enabled, the T1 DS0s are recombined into a user selectable aggregate data rate (V.35, EIA-530, X.21). For increasing 731-D2 aggregate rates, the 731-D2 data is sourced from the T1 DS0s in increasing order, i.e., there is data rate accumulation when DS0s are combined: the T1 DS0 1 issues 1x64 Kbps, T1 DS0s 1 and 2 issue 2x64 Kbps, T1 DS0s 1, 2, and 3, issue 3x64 Kbps, and so forth up to a maximum of 24x64 Kbps. Time slot routing over the HDSL loops follows that shown in *Table 3-9*.


If only one loop is enabled, then a fractional T1 service is provided to the remote site, with a time slot allocation following the consecutive DS0 pattern shown in *Table 3-9*. Up to 12 DS0s may be allotted for the remote device. The maximum aggregate of Nx64 Kbps signals is 12x64 Kbps for a 731D1/D2 for single loop operation.

Point-to-Multipoint Data Routing

When the 721-T1/T2 is used in a P2MP configuration, with remote 721-T2 units, T1 payload is distributed along the HDSL loops in contiguous blocks of DS0s, with the remote T1 payload reconstructed such that the remote (NTU) DS0s are mapped into the same position in the T1 frame as they were at the local (LTU) side. A typical mapping example is shown in *Table 3-10*. The 721-T1 remote units automatically configure themselves based on the setting of their application, Start DS0, and Consecutive DS0s configuration options. Finally, note that the contiguous blocks of DS0s routed to each remote are treated as an aggregate data stream, and therefore, byte alignment is not presently maintained between individual DS0s at the LTU and the corresponding DS0s in the reconstructed T1 frames at the remote units.

When used in a P2MP configuration with remote 731-D1 units, T1 payload is again distributed along the HDSL loops in contiguous blocks of DS0s, but here, the payload is reconstructed at the remote V.35 interface at a data rate that corresponds to the number of DS0s selected to be routed along a particular loop (Nx64 Kbps). The 731-D1 units automatically configure themselves based on the setting of their Application and Data Rate configurations option.

When 721-T1/T2 units are used at the remote sites, up to 12 time slots are available at each remote site. When 731-D1 units are used at the remote sites, a V.35 Nx64 Kbps signal is available at each remote site (up to 12x64 Kbps).



A short burst of errors will occur on a loop which is in normal operation when one of the other HDSL loops transition in or out of normal operation.

721-T1/T2 and 731-D1/D2 remote units cannot simultaneously be connected to a 721-T2 LTU.

Table 3-9 T1 Time Slot Routing

Routed T1 Time Slots												
Loop 1	1	2	3	4	5	6	7	8	9	10	11	12
Loop 2	13	14	15	16	17	18	19	20	21	22	23	24

Table 3-10 Typical T1 P2MP Time Slot Routing (Data Mode)

If Network Configuration Options are set for:													
	Remote 1	Remote 2											
Application:	P2MP												
Loop:	1	2											
Start DS0:	1	11											
Consecutive DS0s:	10	9											
and the Network Configuration Options at each 721-T1 (NTU) are set for:													
	Remote 1	Remote 2											
Application:	P2MP	P2MP											
Loop:	1	1											
Start DS0:	1	11											
Consecutive DS0:	10	9											
Then the resulting time slot allocation at remote 721-T1 T1 interface is:													
Remote 1:													
1	2	3	4	5	6	7	8	9	10	<ts 11 - 24 filled with 1s>			
Remote 2:													
<ts 1 - 10 filled with 1s>			11	12	13	14	15	16	17	18	19	<ts 20 - 24 filled with 1s>	

View H/S Configuration

The View H/S Configuration option displays the Configuration & Selftest Results screen, showing hardware and software configuration data and the results of the last power-up self-test. The information displayed on this screen is intended for maintenance and technical support groups. A typical screen is shown in *Figure 3-13*.




Figure 3-13 Configuration and Self-Test Results Screen

The upper area presents configuration data. The lower area presents the results of the last power-on self-test. *Table 3-11* describes the fields in the screen.

Table 3-11 Configuration and Self Test Results Screen Fields

Software Version	Displays the software version of the 721-T1/T2.
Number of Loops	Displays the number of HDSL loops available.
Checksum	Firmware checksum.
Config Mode	Displays the current configuration mode of the 721-T1/T2: Soft - The 721-T1/T2 is configured under software control. Hard - The 721-T1/T2 is configured by means of the basecard switches.
Remote Feeding	Indicates whether the 721-T1/T2 is power feeding the remote unit, via the interconnecting lines.
The last power-on self-test results area lists each 721-T1/T2 subsystem tested during the self-test, and the self-test result, Pass or Fail. These tested subsystems are non-volatile RAM, T1 Framer, HDSL Channel Unit, HDSL Loop 1 and Loop 2 transceivers; and +12V (Voltage 1) and -12V (Voltage 2) power supplies.	

Maintenance Menu

You may refer to *Chapter 4 - Tests* to perform tests from the optional terminal.

Network Management

A remote DataComm 721-T1/T2 can be used as a Network Managed element when used within a GDC Network Management System. The 721-T1/T2 works together with a GDC SpectraComm Manager, a 701-T2, and GDC management software to form a complete network management system. The management software conforms to the MIB (Management Information Base) II standards set out for SNMP Version 1.0. Refer to the *Operating and Installation Instructions for SpectraComm Manager Card, Publication GDC 048R303-000*.

4 Tests

Overview

This chapter provides instructions for managing the 721 system with the optional terminal and tells you how to enable and disable various loopbacks. The DataComm 721-T2 provides a comprehensive set of features for testing operation and identifying trouble areas, using an optional terminal connected to the control port (CTRL) on the front panel. The 721-T2 displays the status of these tests through the TM indicator on the front panel. Internal functions are checked when you first turn on power and during operation.



The activation of any loopback disrupts the flow of your traffic.

Troubleshooting

- LEDs are Off:
 1. If all the LEDs are Off, verify that the fuse on the rear panel is good and that the unit is properly seated in the shelf.
 2. If the terminal is working, check the status of the \pm supplies on the terminal using the View H/S Config option. If there is a problem with one of the supplies, return the unit for repair.
- Start-up continuously fails:
 1. If an HDSL red ES LED is continuously On during start-up, the card is not receiving a signal from the far end of its channel. Check the loop connections between the two cards (LTU and NTU).
 2. Verify that one card is configured as LTU and the other as NTU.
 3. Check the status of the card using the View H/S Config option.

Metallic Access Testing

The 721-T2 provides front panel bantam jacks for customer use in testing the HDSL and T1 lines and the unit circuitry. *Figure 4-1* illustrates the break-in points of these jacks.




Figure 4-1 Metallic Access Jacks

Maintenance Menu

The Maintenance Menu, shown in *Figure 4-2*, is used to perform maintenance and troubleshooting activities. To open the maintenance menu, select Item 3 on the Main Menu.





Figure 4-2 Maintenance Menu


The functions available from the maintenance menu are as follows:

- Loopbacks
- BER Test
- Set RTC
- Reset Statistics
- HDSL Startup
- Board Reset



Performing loopbacks or BER testing on any single loop will cause a burst on the other loops which are in normal operation.


Loopbacks



The activation of any loopback disrupts the flow of user traffic.

This function is used to enable/disable loopbacks on the user equipment interface (T1) and on the HDSL loops for doing maintenance.

The HDSL systems offered by GDC provide three types of test loopbacks. *Figure 4-3* shows the simplified signal paths when the loopbacks are connected.



T1 Line Loopback	[1]	
T1 Payload Loopback	[2]	The status of these tests are displayed on the front panel indicators and on the terminal screen.
Remote Loopback	[3]	

Figure 4-3 Loopbacks Signal Paths

Loopback Testing (via Front Panel Pushbuttons)

The 721-T1/T2 supports two types of loopbacks at the front panel:

LL - Performs a T1 Line Loopback.

RL - Remote loopback signals the remote unit to loopback the data to the user's equipment interface. This is functional in LTU mode only. The RL switch is disabled when the unit is set for point-to-multipoint.

The forward signal for both of these loopbacks is transparent. Additional loopbacks are available through the optional terminal. The loopbacks are described in paragraph, *Loopback Testing (Soft)*.

ST - Self-Test generates a pattern onto the HDSL transmit line(s) and checks for the incoming pattern on the receive line. This test is described in paragraph *BER test*.

Loopback Testing (via Maintenance Menu)

Figure 4-4 illustrates a typical Loopback Setting screen for an HDSL system module using the T1 interface.




Figure 4-4 Loopbacks Screen

To access the loopbacks function, select Item 1 on the Maintenance Menu. To change the state of a loopback, use the following procedure:

1. Type the number of the line of the desired loopback — this toggles the selected loopback on and off.
2. Highlight the desired option, and press **Enter** to send the command to the HDSL system. The option menu closes and the new selection appears in the corresponding line.
3. To exit and return to the Maintenance Menu, press **Esc**.

T1 Line Loopback

The line loopback is generally used to test the connection between your equipment and the HDSL system module. When the line loopback is connected (On) (Loopback [1]), the data signal received from the local user (via the transmit line of the user equipment interface) is returned on the receive line of that interface. Therefore, during normal operation the user equipment receives its own signal without errors.

The transmit signal from the local user equipment is transparent and thus is sent to the remote HDSL system, but the signal received from the remote HDSL system is blocked from the T1 interface.

T1 Payload Loopback

The payload loopback is generally used to test the connections between the local user equipment and the HDSL system module. When the payload loopback is connected (On) (Loopback [2]), the data portion of the T1 signal received from your installation (via the transmit line of the user's equipment interface) is returned to the data portion of the T1 receive interface. Only the data portion of the signal is returned -- all overhead bits are regenerated by the framing circuitry of the 721-T1/T2. The user's transmit signal is transparent and therefore sent to the remote HDSL system, but the signal received from the remote HDSL system is blocked from the T1 interface.

Remote Loopback

The remote loopback is generally used to test end-to-end proper operation of the HDSL link, and therefore should be initiated by the LTU only and used after normal operation is obtained.

When the remote loopback is connected (On) (loopback [3]), the data received by the remote module from the local user is returned by the HDSL system module on the receive path, within the remote user equipment interface. Therefore, during normal operation the local user equipment should receive its own signal without errors.

The local user's transmit signal is also passed to the remote user equipment that is connected to the HDSL system. But, the signal transmitted by the remote user is disconnected from the HDSL receiver.

Test Loopbacks - A Consideration

The test loopbacks are designed to allow systematic testing of the signal paths along the link, starting from one end of the link (the local HDSL module). In most situations, you should initiate the loopbacks from the side serving as the LTU because this enables you to follow the signal path starting from the office and continuing toward the end user. We recommend this testing sequence:

1. Line loopback.
2. Payload loopback.
3. Remote loopback.

This is also the order in which the loopbacks are listed on the loopbacks screen. Activate only one loopback at a time.

BER Test

Method

Bit Error Rate (BER) testing is done by repeatedly transmitting a pseudo test sequence having a length of $2^{15}-1$ bits and comparing, by means of an error detector, the received sequence. Any difference is assumed to be an error and is counted. To perform a meaningful comparison, the error counting is inhibited until the error detector becomes synchronized with the incoming sequence. During this synchronization it is possible to see a burst of 255 errors.


During this testing, user traffic is interrupted. You can do BER tests in an end-to-end mode that requires both LTU and NTU BER testers to be on. If testing is initiated at one end, a loopback along the signal path needs to be connected. The loopback can be a physical connection made somewhere along the signal path or a test loopback activated at the desired location as described in the *Loopbacks* section. Alternatively, an external BERT may be connected to the remote unit to make testing easier.

The measurement is carried out over discrete intervals (an interval corresponds to the time required for the transmission of a block of 2^{21} bits). The number of errors counted in each interval is up to 255. If the actual number of errors in a given interval is higher, only this maximum count is considered in the calculation of the BER. The calculated BER is updated at the end of each interval.


When configured as multi-point, you can use the BER tester on individual loops. When used in point-to-point operation both HDSL loops are used to transmit the $2^{15}-1$ bit pattern.

The bit error rate test can be performed over an individual HDSL loop or over the entire HDSL bandwidth. But only one BERT test can be active at a time. For point-to-point performance, BER test can be applied only if done simultaneously over all the loops. For point-to-multipoint application, the user can invoke BERT test on individual HDSL loops.

BER test can be invoked through the GDC UAS controller, supervisory terminal port or front panel switch. The front panel TM LED illuminates when the BER test is activated. When the error detector is in sync and detects no errors, the TM LED is constant, but when the error detector is not in sync or detects some errors, the TM LED blinks. The TM LED does not blink if the data detected is all 1s or all 0s.




The internal BER test pattern generates data which is inverted relative to test equipment connected at the remote user-equipment interface.




Master Self-Test:

- (1) At the remote unit, attach external test equipment configured with test pattern 2^{15} and with data inverted. (A loopback plug may be used in place of test equipment.)
- (2) Enable Master BER test for all loops.
- (3) Proper operation is indicated by SYNC status and no errors.




Remote Self-Test:

- (1) At the Master unit, attach external test equipment configured with test pattern 2^{15} and with data inverted. (A loopback plug may be used in place of test equipment.)
- (2) Enable Remote BER test for all loops.
- (3) Proper operation is indicated by SYNC status and no errors.



Self-Test with Remote Loopback:

- (1) Enable Master BER test for all loops and with Remote Loopback.
- (2) Proper operation is indicated by SYNC status and no errors.



End-to-End Self-Test:

- (1) Enable BER test for all loops on both Master and Remote units.
- (2) Proper operation is indicated by SYNC status and no errors.

Figure 4-5 Test Configuration

BER Screen Description

A typical *BER Test* screen for the HDSL system is shown in *Figure 4-6*.




Figure 4-6 HDSL BER Test Screen

The dialog box used to control BER testing has two areas:

- The top area is used to display BER results.
- The bottom area is used to select the desired HDSL test loop and to start/stop BER measurement.

The fields of the BER Test screen are described in *Table 4-1*.

Table 4-1 BER Test Screen Fields


Status	Displays the status of the error detector: Sync - The error detector is synchronized, and the BER measurement is possible; Out-of-Sync - The error detector is not synchronized, and BER measurement is inhibited.
Errors	Displays the number of errors counted up to this point.
Intervals	Displays the number of measurement intervals up to this point.
BER	Displays the BER calculated up to this point.
HDSL Loop	Displays the HDSL loop to be tested. Each individual loop or all loops as an aggregate may be selected.
Loopback	Displays the current state of the loopback activated for the BER test: None_- No loopback has been activated. In this case, an external loopback, e.g., a physical loopback connection, must be connected before starting the BER test; Remote Local - Remote local loopback is activated for the BER test.
Execution	Displays the next state of BER measurement: Stop - BER measurement disabled; Start - BER measurement enabled.

Operation

1. To display the BER Test screen, select Item 2 on the Maintenance Menu.
2. Select desired HDSL test loop by moving the selection block to HDSL loop field. Press space bar to select desired HDSL loop.
3. Make sure a loopback is activated. If the Loopback field displays None and no external loopback is currently connected, change the state of the loopback used for BER measurement. Move the selection block to the Loopback line and press the space bar.

To enable or disable BER testing:

1. To start the BER measurement, move the selection block to the Execution field and press the space bar. The Execution field now shows Stop.
2. To stop the BER measurement, move the selection block to the Execution field and press the space bar. The Execution field now shows Start. Note that although BER measurements have stopped, the unit continues to transmit the test pattern until you exit the BER Test screen.
3. To exit and return to the Maintenance Menu, make sure that BER testing has been disabled, and press Esc.



You cannot exit the BER TEST screen while a BER test is running.

When starting or stopping the BER TEST on one of the HDSL loop, other loop(s) will see bursted errors on its data.

BER test detector will synchronize and show extensively error free for 1s and 0s.

Set RTC

The Set RTC option permits you to set the real-time clock of the 721-T1/T2. Choosing this option displays the Set RTC screen. A typical screen is shown in Figure 4-7.




Figure 4-7 Set RTC Screen

The screen includes the two fields described in *Table 4-2*.


Table 4-2 Set RTC Screen Fields

Time	Displays the time in 24-hr military format showing hours:minutes:seconds retrieved from the unit at the time the screen is opened.
Date	Displays the date (day/month/year) retrieved from the unit at the time the screen is opened.

Operation

To change the current time or date, use the following procedure:

1. Move the selection block to the desired line and press **Enter**.
2. Type the new time or date in the format seen on the screen, then press **Enter**. The option menu closes, and the new time and/or date appears in the corresponding line.
3. To save changes, press **CTRL-W**.
4. To quit and cancel the changes made in this screen, press **ESC** without pressing **CTRL-W**.
5. To exit and return to the maintenance menu, press **ESC**.



The 721-T1/T2 internal time is updated at the instant you press CTRL-W.

Reset Statistic

The Reset Statistics option resets all the performance statistics entries of the 721-T1/T2.

Operation

To instruct the 721-T1/T2 to reset all the performance statistics counters:

1. Select Item 4 on the Maintenance Menu. This displays a dialog box with two options: **Yes** and **No**.
2. To reset the statistics, move the selection block to **Yes**, and press **Enter**.
3. To exit without resetting, press **ESC**, or move the selection block to **No** and press **Enter**.

HDSL Start-Up

This option is used to manually initiate the 721-T1/T2 HDSL Loop start-up process. Normally this process is automatically performed at link initialization and whenever the synchronization between two linked HDSL units is lost.



The activation of this function disrupts the transfer of data through the link for a short time.

To instruct the 721-T1/T2 to perform the start-up process, select Item 5 on the Maintenance Menu.

Board Reset

This option is used to reset the 721-T1/T2. To reset the 721-T1/T2, select Item 6 on the Maintenance Menu. After a few seconds, the opening screen appears. The unit performs the start-up process and displays the Main Menu screen.



The activation of this function disrupt the transfer of data through the link for a short time.

Index

- A
 - Alarm Treshold Configuration 3-32
 - ANSI Statistics Operation 3-9
 - Applications 1-3
- B
 - BER Screen Description 4-8
 - BER Test 4-6
 - BER Test Screen Fields 4-9
 - Board Reset 4-12
- C
 - Cancel Start-up 3-12
 - Configuration 3-6
 - Configuration and Self Test Results Screen Fields 3-20
 - Configuration and Self-Test Results Screen 3-20
 - Configuration Menu 3-12
 - Configuration Menu Screen 3-13
 - Configurations 1-5
 - Control Port Characteristics 3-3
 - Current Performance 3-27
- D
 - DataComm and Universal System Shelf Rear Panel Connections 2-8
 - DE-23E Enclosure 2-7
 - DE-7 Standalone Enclosure Rear Panel 2-6
 - Diagnostic Menu 3-7
 - Diagnostics 3-6
 - Diagnostics Menu Screen 3-7
 - Diagnostics/Network Management 1-9
- E
 - Electrical Connections 2-6
 - Equipment List 1-9
- F
 - Field Editing 3-5
 - Field Navigation 3-5
 - Front Panel 3-1
 - Front Panel of the 721-T2 3-2
 - Full T1 1-3
 - Full T1 to Remote V.35 1-3
 - Full T1 to Slave V.35 1-3
- H
 - HDSL Alarm Object Identifier Definitions 3-33
 - HDSL BER Test Screen 4-9
 - HDSL Diagnostic 3-25
 - HDSL Diagnostic Results 3-25
 - HDSL Fractionalization 3-32
 - HDSL Monitoring 3-9
 - HDSL Monitoring Screen 3-10
 - HDSL Monitoring Screen Fields 3-10
 - HDSL Monitoring Screen Operation 3-10
 - HDSL Performance 3-25, 3-27
 - HDSL Start-Up 4-11
 - HDSL Status 3-11, 3-31
 - HDSL Status Screen 3-11
 - HDSL Status Screen Fields 3-12
 - HDSL Status Screen Operation 3-12
 - HDSL Units at Two Locations 1-4
- I
 - Installation 2-1
 - Interface Configuration 3-15
 - Interface Configuration Operation 3-16
 - Interface Configuration Screen 3-15
 - Interface Configuration Screen Fields 3-16
 - Interval Performance 3-28
- L
 - Loop/E1 Performance Interval Maintenance 3-27
 - Loopback Testing (via Front Panel Pushbuttons) 4-4
 - Loopback Testing (via Maintenance Menu) 4-4
 - Loopbacks 4-3
 - Loopbacks Screen 4-5
 - Loopbacks Signal Paths 4-4
- M
 - Main Menu 3-6
 - Main Menu Screen 3-6
 - Maintenance 3-7, 3-22
 - Maintenance Menu 4-2
 - Maintenance Menu Screen 4-3
 - Menu Selection 3-5
 - Metallic Access Jacks 4-2
 - Metallic Access Testing 4-1
 - Method 4-6
 - MIB Tables 3-21
- N
 - Network Configuration 3-16
 - Network Configuration Screen 3-17
 - Network Management 1-9, 3-20
- O
 - Opening Screen 3-4
 - Operating Procedures 3-5
 - Operation 3-17, 4-10, 4-11
 - Option Selection 2-4
 - Option Switch and Jumper Locations 2-5
- P
 - Point-to-Multipoint 1-4
 - Point-to-Multipoint Data Routing 3-18
 - Point-to-Point 1-3
 - Point-to-Point Application 1-5
 - Point-to-Point Data Routing 3-18
 - Point-to-Point MultiPoint - T1 1-7
 - Point-to-Point MultiPoint - V.35 1-8
 - Point-to-T1 Multipoint 1-4
 - Point-to-V.35 Multipoint 1-5
 - Preoperational Configuration 2-9
- Q
 - Quitting without Saving 3-5

