Help for ix1 User interface

Topics:

Select Item with Cursor and press F1

The Bin File will be downloaded onto the ISDN board.

Search for the file on the hard disk

Please select the D channel protocol which you want to use with your ISDN adapter.

Select the type of line access, usually it will be a dial up line.

Please enter a TEI manually if your provider has told you one.

The ISDN adapter has to dial a dialnumber.

The ISDN line is fixed, you wont have to dial.

Channel bundling on line level.

Is a D Channel used?

At TE Side

At NT Side

The methode for encoding analog signals. In the USA usually it is µ-Law, in other countries A-Law.

Please enter the SPIDs. You get the SPIDs from your service provider, if needed.

Please enter the Directory Numbers. You get the DN from your service provider.

The Boot File is used for downloading the Bin File.

Use Point to Point only when you are told so by your provider.

Advanced configuration.

Use the configuration of the actual line for all lines.

Description of the selected Bin File.

Description of the selected Boot File.

If you connect two boards back to back, one has to be Clock Master, the other Clock Slave.

Interrupt

IO Base Address

Mapped Memory

Jumper Setting

Select the country from which you are calling.

If you are using the MVIP bus, exactly one of the MVIP cards has to be configered as a MVIP Master, all other cards must be MVIP Slave.