

TITLE: Information technology - International Standardized Profile AMM11: MMS  
General Applications Base Profile - Part 2: Common MMS Requirements

SOURCE: Editor

STATUS: Submittal copy, June 1994

This document has been prepared based on the comments from the OIW's MMS SIG, EWOS's EG MMS and AOW's MMS SIG. The text has been revised to be as close to the final document as possible at this time. Additions to draft six text are denoted by highlighted text. Deletions are denoted by ~~strikeout~~.

# Contents

Forewordvii

Introductionvii

1. Scope 1
  - 1.1. General 1
  - 1.2. Position within the Taxonomy 1
2. Normative References 1
3. Definitions 2
4. Abbreviations 2
5. Conformance Requirements 3
  - 5.1. General Requirements for use of all parts of MMS 3
    - 5.1.1. Max supported PDU size 3
    - 5.1.2. FileName 4
  - 5.2. Service-specific Requirements 4
    - 5.2.1. Environment and General Management 4
      - 5.2.1.1. Initiate Service 4
        - 5.2.1.1.1. Negotiation of MMS Abstract Syntaxes 4
        - 5.2.1.1.2. Max Serv Outstanding 4
        - 5.2.1.1.3. Local Detail Calling 4
        - 5.2.1.1.4. Local Detail Called 5
        - 5.2.1.1.5. Rules of Extensibility 5
      - 5.2.2. VMD Support 5
        - 5.2.2.1. Get Capability List Service 5
      - 5.2.3. Domain Management 5
        - 5.2.3.1. List Of Capabilities 6
        - 5.2.3.2. Initiate Download Sequence Service 6
        - 5.2.3.3. Download Segment Service 6
        - 5.2.3.4. Terminate Download Sequence Service 7
        - 5.2.3.5. Initiate Upload Sequence Service 7
        - 5.2.3.6. Upload Segment Service 7
        - 5.2.3.7. Get Domain Attributes Service 7
      - 5.2.4. Program Invocation Management 7
        - 5.2.4.1. Start 7
        - 5.2.4.2. Stop 7
        - 5.2.4.3. Resume 8
        - 5.2.4.4. Reset 8
        - 5.2.4.5. Kill 8
      - 5.2.5. Variable Access 8
        - 5.2.5.1. Scattered Access 8
        - 5.2.5.2. Floating Point 8
        - 5.2.5.3. List Of Variables 8
        - 5.2.5.4. Parameter CBBs 9
        - 5.2.5.5. Named Variable Scope 9
        - 5.2.5.6. Address Types 9
      - 5.2.6. Semaphore Management 9
      - 5.2.7. Operator Communication 9
      - 5.2.8. Event Management 9
      - 5.2.9. Journal Management 9
      - 5.2.10. File Access 10
      - 5.2.11. File Management 10

## 5.2.12. Data Exchange Management 10

## Annex A - ISPICS Requirements List 13

## A.1. General 13

## A.2. Classification of Requirements 13

- A.2.1. Base Column 13
- A.2.2. F/S Column 13
- A.2.3. Value/Reference 14
- A.2.4. Conditional MACROs 14

## A.3. Supported MMS PDU's 15

- A.3.1. Environment and General Management 16
- A.3.2. MMS Modifiers 16
- A.3.3. Parameter CBBs 16
- A.3.4. VMD Support 17
- A.3.5. Domain Management 18
- A.3.6. Program Invocation Management 18
- A.3.7. Variable Access 19
- A.3.8. Semaphore Management 20
- A.3.9. Operator Communication 20
- A.3.10. Event Management 20
- A.3.11. Journal Management 21
- A.3.12. File Access 21
- A.3.13. File Management 21
- A.3.14. Data Exchange Management 22
- A.3.15. Additional PDUs 22

## A.4. PDU-Specific Requirements 22

- A.4.1. Environment and General Management 23
  - A.4.1.1. Initiate Request PDU 23
  - A.4.1.2. Initiate Response PDU 23
  - A.4.1.3. Initiate Error PDU 23
  - A.4.1.4. Conclude Request PDU 24
  - A.4.1.5. Conclude Response PDU 24
  - A.4.1.6. Conclude Error PDU 24
  - A.4.1.7. Cancel Request PDU 24
  - A.4.1.8. Cancel Response PDU 24
  - A.4.1.9. Cancel Error PDU 25
  - A.4.1.10. Reject PDU 25
- A.4.2. VMD Support 25
  - A.4.2.1. Status Request PDU 25
  - A.4.2.2. Status Response PDU 26
  - A.4.2.3. Status Error PDU 26
  - A.4.2.4. Unsolicited Status PDU 26
  - A.4.2.5. GetNameList Request PDU 27
  - A.4.2.6. GetNameList Response PDU 27
  - A.4.2.7. GetNameList Error PDU 27
  - A.4.2.8. Identify Request PDU 28
  - A.4.2.9. Identify Response PDU 28
  - A.4.2.10. Identify Error PDU 28
  - A.4.2.11. GetCapabilityList Request PDU 28
  - A.4.2.12. GetCapabilityList Response PDU 29
  - A.4.2.13. GetCapabilityList Error PDU 29
- A.4.3. Domain Management 29
  - A.4.3.1. InitiateDownloadSequence Request PDU 29
  - A.4.3.2. InitiateDownloadSequence Response PDU 30
  - A.4.3.3. InitiateDownloadSequence Error PDU 30

- A.4.3.4. DownloadSegment Request PDU 30
- A.4.3.5. DownloadSegment Response PDU 31
- A.4.3.6. DownloadSegment Error PDU 31
- A.4.3.7. TerminateDownloadSequence Request PDU 31
- A.4.3.8. TerminateDownloadSequence Response PDU 32
- A.4.3.9. TerminateDownloadSequence Error PDU 32
- A.4.3.10. InitiateUploadSequence Request PDU 33
- A.4.3.11. InitiateUploadSequence Response PDU 33
- A.4.3.12. InitiateUploadSequence Error PDU 33
- A.4.3.13. UploadSegment Request PDU 33
- A.4.3.14. UploadSegment Response PDU 34
- A.4.3.15. UploadSegment Error PDU 34
- A.4.3.16. TerminateUploadSequence Request PDU 34
- A.4.3.17. TerminateUploadSequence Response PDU 35
- A.4.3.18. TerminateUploadSequence Error PDU 35
- A.4.3.19. RequestDomainDownload Request PDU 35
- A.4.3.20. RequestDomainDownload Response PDU 36
- A.4.3.21. RequestDomainDownload Error PDU 36
- A.4.3.22. RequestDomainUpload Request PDU 36
- A.4.3.23. RequestDomainUpload Response PDU 37
- A.4.3.24. RequestDomainUpload Error PDU 37
- A.4.3.25. LoadDomainContent Request PDU 37
- A.4.3.26. LoadDomainContent Response PDU 38
- A.4.3.27. LoadDomainContent Error PDU 38
- A.4.3.28. StoreDomainContent Request PDU 38
- A.4.3.29. StoreDomainContent Response PDU 39
- A.4.3.30. StoreDomainContent Error PDU 39
- A.4.3.31. DeleteDomain Request PDU 39
- A.4.3.32. DeleteDomain Response PDU 40
- A.4.3.33. DeleteDomain Error PDU 40
- A.4.3.34. GetDomainAttributes Request PDU 40
- A.4.3.35. GetDomainAttributes Response PDU 41
- A.4.3.36. GetDomainAttributes Error PDU 41
- A.4.4. Program Invocation Management 41
  - A.4.4.1. CreateProgramInvocation Request PDU 41
  - A.4.4.2. CreateProgramInvocation Response PDU 42
  - A.4.4.3. CreateProgramInvocation Error PDU 42
  - A.4.4.4. DeleteProgramInvocation Request PDU 42
  - A.4.4.5. DeleteProgramInvocation Response PDU 43
  - A.4.4.6. DeleteProgramInvocation Error PDU 43
  - A.4.4.7. Start Request PDU 43
  - A.4.4.8. Start Response PDU 44
  - A.4.4.9. Start Error PDU 44
  - A.4.4.10. Stop Request PDU 44
  - A.4.4.11. Stop Response PDU 45
  - A.4.4.12. Stop Error PDU 45
  - A.4.4.13. Resume Request PDU 45
  - A.4.4.14. Resume Response PDU 46
  - A.4.4.15. Resume Error PDU 46
  - A.4.4.16. Reset Request PDU 46
  - A.4.4.17. Reset Response PDU 47
  - A.4.4.18. Reset Error PDU 47
  - A.4.4.19. Kill Request PDU 47
  - A.4.4.20. Kill Response PDU 47
  - A.4.4.21. Kill Error PDU 48
  - A.4.4.22. GetProgramInvocationAttributes Request PDU 48
  - A.4.4.23. GetProgramInvocationAttributes Response PDU 48
  - A.4.4.24. GetProgramInvocationAttributes Error PDU 49
- A.4.5. Variable Access 49

- A.4.5.1. Read Request PDU 49
    - A.4.5.1.1. VariableAccessSpecification 50
    - A.4.5.1.2. VariableSpecification 50
    - A.4.5.1.3. Address 50
    - A.4.5.1.4. TypeSpecification 51
    - A.4.5.1.5. AlternateAccess 52
    - A.4.5.1.6. AccessSelection 52
    - A.4.5.1.7. SelectAccess 52
    - A.4.5.1.8. IndexRange 53
  - A.4.5.2. Read Response PDU 53
    - A.4.5.2.1. Data 53
  - A.4.5.3. Read Error PDU 54
  - A.4.5.4. Write Request PDU 54
  - A.4.5.5. Write Response PDU 54
  - A.4.5.6. Write Error PDU 55
  - A.4.5.7. InformationReport PDU 55
  - A.4.5.8. GetVariableAccessAttributes Request PDU 55
  - A.4.5.9. GetVariableAccessAttributes Response PDU 56
  - A.4.5.10. GetVariableAccessAttributes Error PDU 56
  - A.4.5.11. DefineNamedVariable Request PDU 56
  - A.4.5.12. DefineNamedVariable Response PDU 57
  - A.4.5.13. DefineNamedVariable Error PDU 57
  - A.4.5.14. DeleteVariableAccess Request PDU 57
  - A.4.5.15. DeleteVariableAccess Response PDU 58
  - A.4.5.16. DeleteVariableAccess Error PDU 58
  - A.4.5.17. DefineNamedVariableList Request PDU 58
  - A.4.5.18. DefineNamedVariableList Response PDU 59
  - A.4.5.19. DefineNamedVariableList Error PDU 59
  - A.4.5.20. GetNamedVariableListAttributes Request PDU 59
  - A.4.5.21. GetNamedVariableListAttributes Response PDU 60
  - A.4.5.22. GetNamedVariableListAttributes Error PDU 60
  - A.4.5.23. DeleteNamedVariableList Request PDU 60
  - A.4.5.24. DeleteNamedVariableList Response PDU 61
  - A.4.5.25. DeleteNamedVariableList Error PDU 61
  - A.4.5.26. DefineNamedType Request PDU 61
  - A.4.5.27. DefineNamedType Response PDU 61
  - A.4.5.28. DefineNamedType Error PDU 62
  - A.4.5.29. GetNamedTypeAttributes Request PDU 62
  - A.4.5.30. GetNamedTypeAttributes Response PDU 62
  - A.4.5.31. GetNamedTypeAttributes Error PDU 63
  - A.4.5.32. DeleteNamedType Request PDU 63
  - A.4.5.33. DeleteNamedType Response PDU 63
  - A.4.5.34. DeleteNamedType Error PDU 63
- A.4.6. Semaphore Management 64
  - A.4.7. Operator Communication 64
    - A.4.7.1. Input Request PDU 64
    - A.4.7.2. Input Response PDU 64
    - A.4.7.3. Input Error PDU 65
    - A.4.7.4. Output Request PDU 65
    - A.4.7.5. Output Response PDU 65
    - A.4.7.6. Output Error PDU 66
  - A.4.8. Event Management 66
  - A.4.9. Journal Management 66
  - A.4.10. File Access 66
  - A.4.11. File Management 66
  - A.4.12. Data Exchange Management 66

## Foreword

The ISO/IEC ISP 14226 specifies the AMM11 MMS General Applications International Standardized Profile. This ISP has three parts:

Part 1 - Specification of ACSE, Presentation, and Session Protocols for the use by MMS

Part 2 - Common MMS Requirements

Part 3 - Specific MMS Requirements

This part of the ISO/IEC ISP 14226 is produced and approved by ISO TC 184. This Group includes ISO/IEC Member Bodies and S-liaison organizations. The S-liaison organizations that have contributed to the production of this draft are

Asia-Oceania Workshop (AOW)

European Workshop for Open Systems (EWOS)

OSE Implementors Workshop (OIW)

## Introduction

This draft for an International Standardized Profile (ISP) is defined within the context of Functional Standardization, in accordance with the principles specified by ISO/IEC TR 10000, "Framework and Taxonomy of International Standardized Profiles". The context of Functional Standardization is one part of the overall field of Information Technology (IT) standardization activities, covering base standards, profiles, and registration mechanisms. A profile defines a combination of base standards that collectively perform a specific well-defined IT function. Profiles standardize the use of options and other variations in the base standards, and provide a basis for the development of uniform, internationally recognized system tests.

# **Information Technology - International Standardized Profile AMM11 - MMS General Applications Base Profile -**

## **PART 2: Common MMS Requirements**

### **. Scope**

### **. General**

This part of ISO/IEC ISP 14226 specifies the common MMS requirements that form the basis for part 3 of this ISP and for other ISPs referencing this part. This part when used in conjunction with other ISPs specifies how the MMS standard shall be used to provide the MMS functions required by applications controlling a full range of devices in the scope of MMS.

### **. Position within the Taxonomy**

This part of ISO/IEC ISP 14226 is the second part of a multi-part ISP identified in ISO/IEC TR 10000-2 as "AMM11, MMS General Applications Base Profile".

It may be combined with any T-Profile specifying the OSI connection-mode transport service.

### **. Normative References**

The following documents contain provisions which, through reference in this text, constitute provisions of this profile. At the time of publication, the editions indicated were valid. All documents are subject to revision, and parties to agreements based on this profile are warned against automatically applying any more recent editions of the documents listed below, since the nature of references made by ISPs to such documents is that they may be specific to a particular edition. Members of IEC and ISO maintain registers of currently valid International Standards and ISPs, and CCITT maintains published editions of its current Recommendations.

- ISO/IEC 9506-1:1990, Industrial automation systems - Manufacturing Message Specification - Part 1 - Service definition
- ISO/IEC 9506-2:1990, Industrial automation systems - Manufacturing Message Specification - Part 2 - Protocol specification
- ISO/IEC TR 10000-1:1992, Information Technology - Framework and taxonomy of International Standardized Profiles - Part 1 : Framework.
- ISO/IEC TR 10000-2:1992, Information Technology - Framework and taxonomy of International Standardized Profiles - Part 2 : Taxonomy of Profiles.

- ISO/IEC ISP 10607-3:1991, Information Technology - International Standardized Profiles AFT nn-File Transfer, Access and Management - Part 3: AFT 11 - Simple File Transfer Service (unstructured)
- ISO/IEC 9506 - Technical Corrigenda 1:1993
- ISO/IEC 9506-1 - Amendment 1:1993 Data Exchange
- ISO/IEC 9506-2 - Amendment 1:1993 Data Exchange
- ISO/IEC DISP 14226-1, Information Technology - International Standardized Profile AMM11:MMS General Applications Base Profile - Part 1: Specification of ACSE, Presentation, and Session Protocols for use by MMS

### **. Definitions**

Unless specifically noted, terms used in this part shall be as defined in the referenced base standards.

An MMS implementation is a realization of an MMS user together with its underlying MMS provider.

A calling MMS implementation is the MMS implementation that issues the Initiate request primitive.

A called MMS implementation is the MMS implementation that issues the Initiate response primitive.

### **. Abbreviations**

Unless specifically noted, abbreviations used in this part shall be as defined in the referenced base standards.

Client-CR      Client Conformance Requirements

Server-CR      Server Conformance Requirements



### **. Conformance Requirements**

This part of ISO/IEC ISP 14226 states requirements upon implementations to achieve interworking. A claim of conformance to this part of ISO/IEC ISP 14226 is a claim that all requirements in the relevant base standards are satisfied, and that all requirements in the following Clauses and in annex A are satisfied. Annex A states the relationship between these requirements and those of base standards.

The conformance requirements of this ISP are described in terms of "Client Conformance Requirements (Client-CR)" and "Server Conformance Requirements (Server-CR)" for each service.

An MMS implementation compliant with the Client-CR for all services in this ISP is called a "Client Implementation".

An MMS implementation compliant with the Server-CR for all services in this ISP is called a "Server Implementation".

### **. General Requirements for use of all parts of MMS**

To achieve interworking, each server implementation shall be able to accept an association with a client implementation.

### **. Max supported PDU size**

The `max_mms_pdu_size` is defined as the maximum number of octets in an MMSpdu encoded using the negotiated transfer syntax. The size shall apply to all MMSpdu's with the exception of the Initiate-request PDU, Initiate-response PDU and Initiate-error PDU. The `max_mms_pdu_size` shall be negotiated during connection initiation using the `LocalDetailCalling` and `LocalDetailCalled` parameters of the MMS Initiate service.

The negotiated `max_mms_pdu_size` shall be applied as follows:

- Any received MMSpdu whose length is less than or equal to the negotiated `max_mms_pdu_size` shall be properly parsed and processed.
- An MMS implementation should not send an MMSpdu whose size exceeds the negotiated `max_mms_pdu_size`. If an MMS implementation sends an MMSpdu that exceeds the negotiated `max_mms_pdu_size`, then it shall be prepared to receive a Reject PDU. Should an MMS implementation receive an MMSpdu that exceeds the negotiated `max_mms_pdu_size`, it shall either reject the MMSpdu or accept the MMSpdu as if no size violation had occurred and performed the expected processing.
- If an MMS implementation is unable to send a service response because the response would exceed the `max_mms_pdu_size`, then it shall return a Service response (-) with an error class of SERVICE and an error code of OTHER.
- When rejecting an MMSpdu because it exceeds the negotiated `max_mms_pdu_size`, an MMS implementation shall use a Reject PDU Type of PDU-ERROR and a Reject Code of INVALID-PDU in the resulting Reject PDU.

### **. FileName**

Restrictions for the use of the type FileName in the MMS Abstract Syntax are specified in section 9.1 of ISO/IEC ISP 10607-3.

#### **. Service-specific Requirements**

#### **. Environment and General Management**

#### **. Initiate Service**

#### **. Negotiation of MMS Abstract Syntaxes**

On the A-Associate response the MMS responder shall not accept more than one presentation context derived from an MMS abstract syntax. For this agreement, the term 'MMS abstract syntax' shall represent an abstract syntax from the set containing the abstract syntax defined in clause 19 of ISO/IEC 9506-2 and abstract syntaxes defined by MMS companion standards.

#### **. Max Serv Outstanding**

An MMS implementation which intends to conform only with the Client Conformance Requirements for Requester CBB's shall:

- a) propose one or greater for the value of the Proposed Max Serv Outstanding Called parameter in the Initiate service when initiating the application association (calling);
- b) offer one or greater for the value of the Negotiated Max Serv Outstanding Calling parameter in the Initiate service when receiving the application association initiation (called);

An MMS implementation which intends to conform to one or more Server Conformance Requirements for Responder CBB's shall:

- a) propose one or greater for the value of the Proposed Max Serv Outstanding Calling parameter in the Initiate service when initiating the application association (calling);
- b) offer one or greater for the value of the Negotiated Max Serv Outstanding Called parameter in the Initiate service when receiving the application association initiation (called);

#### **. Local Detail Calling**

The Local Detail Calling parameter in the Initiate request primitive shall specify the max\_mms\_pdu\_size guaranteed to be supported by the calling MMS implementation. If the Local Detail Calling parameter is absent from the request primitive, then the calling MMS implementation shall guarantee support for an unlimited max\_mms\_pdu\_size.

If present in the request or indication primitives, the Local Detail Calling parameter shall not be less than 64; however, it is recommended that at least 512 octets be

### **. Local Detail Called**

The Local Detail Called parameter in the Initiate response primitive shall specify the negotiated max\_mms\_pdu\_size for the application association.

If the Local Detail Calling parameter is omitted in the indication primitive, then the Local Detail Called parameter:

- a) may be omitted from the response, indicating that the calling MMS implementation and the called MMS implementation are prepared to support an unbounded max\_mms\_pdu\_size;
- b) may be specified in the response, indicating a requirement to support the specified value for max\_mms\_pdu\_size.

If the Local Detail Calling is included in the request, then this parameter shall be present in the response and its value shall be less than or equal to the value of the Local Detail Calling parameter of the request.

If present in the response, the Local Detail Called shall not be less than 64; however, it is recommended that at least 512 octets be supported.

### **. Rules of Extensibility**

Any additional valid tagged ASN.1 values received as sequence elements in the parameters of the Initiate-RequestPDU, the Initiate-ResponsePDU, or the Initiate-ErrorPDU shall be ignored for upward compatibility purposes.

Implementations shall be capable of parsing up to 128 bits in the services supported field of either the Initiate-RequestPDU or Initiate-ResponsePDU. Implementations shall be capable of parsing up to 32 bits in the parameter CBB field of either the Initiate-RequestPDU or the Initiate-ResponsePDU. In both cases, the behaviour of the implementation shall be no different than if the PDU received had not contained additional bits.

### **. VMD Support**

#### **. Get Capability List Service**

Only one capability shall be described in each Visible String of the SEQUENCE OF.

#### **. Domain Management**

#### **. List Of Capabilities**

Only one capability shall be described in each Visible String of the SEQUENCE OF.

The order of the strings within the List Of Capabilities parameter may have significance to the server implementation and shall be preserved.

**. Initiate Download Sequence Service**

The List Of Capabilities parameter shall follow the limitations of 5.2.3.1.

The syntax and semantics of the capabilities shall be defined by the Server implementation in the PICS. Any deviation from the defined syntax and semantics shall be reasons for the Server implementation to return a service error with Error Class equal to RESOURCE and Error Code equal to CAPABILITY-UNKNOWN.

**. Download Segment Service**

A client implementation that receives a Download Segment indication after issuing a Download Segment Result (+) with the More Follows parameter equal to FALSE or after issuing a Download Segment Result (-) shall issue either a service error, specifying an Error Class equal to SERVICE and an Error Code equal to PRIMITIVES-OUT-OF-SEQUENCE, or an Abort Request.

**. Terminate Download Sequence Service**

If a client implementation receives a Terminate Download Sequence indication in which the Discard parameter is absent and the client implementation has not issued a Download Segment response with the More Follows parameter equal to FALSE for that Domain, it shall behave as if it had received a Terminate Download Sequence indication with the Discard parameter present with the Error Class equal to VMD-STATE and Error Code equal to DOMAIN-TRANSFER-PROBLEM. It is then up to the client implementation to determine the true state of the Domain and take any recovery action.

**. Initiate Upload Sequence Service**

The List Of Capabilities parameter shall follow the limitations of 5.2.3.1.

**. Upload Segment Service**

A server implementation that receives a Upload Segment indication for an Upload State Machine for which it has issued an Upload Segment Result (-) or an Upload Segment Result (+) with the More Follows parameter equal to FALSE, shall issue either a service error, specifying an Error Class equal to SERVICE and an Error Code equal to PRIMITIVES-OUT-OF-SEQUENCE, or an Abort Request.

**. Get Domain Attributes Service**

The List Of Capabilities parameter shall follow the limitations of 5.2.3.1.

**. Program Invocation Management****. Start**

A Program Invocation State of NON-EXISTENT shall be returned in a Result (-) when a request to start a non-existent Program Invocation is received.

**. Stop**

A Program Invocation State of NON-EXISTENT shall be returned in a Result (-) when a request to stop a non-existent Program Invocation is received.

**. Resume**

A Program Invocation State of NON-EXISTENT shall be returned in a Result (-) when a request to resume a non-existent Program Invocation is received.

**. Reset**

A Program Invocation State of NON-EXISTENT shall be returned in a Result (-) when a request to reset a non-existent Program Invocation is received.

**. Kill**

A Program Invocation State of NON-EXISTENT shall be returned in a Result (-) when a request to kill a non-existent Program Invocation is received.

**. Variable Access****. Scattered Access**

It is strongly recommended that for services which use variable access, a Variable List Name or a List Of Variable be used instead of Scattered Access.

No implementations shall be required to propose or accept the VSCA Parameter CBB.

**. Floating Point**

It is strongly recommended that for services which use floating point types or values, that the choice of floating-point in the Data and TypeSpecification productions be used instead of the choice of real.

No implementations shall be required to propose or accept the REAL Parameter CBB.

Any implementation which supports data of the MMS floating-point type, shall be capable of supporting a size parameter of format width 32 and exponent width 8.

Implementations that provide support for floating point data and types shall support the choice of "floating point" in the Data and TypeSpecification productions.

**. List Of Variables**

The order of Variable Specification that appears in the List Of Variable shall not constrain the temporal order of the access to individual variables by the V-Put and V-Get functions in the Server implementation.

**. Parameter CBBs**

Each server implementation that claims support for the Read, Write, or InformationReport service shall be capable of supporting either the VNAM or VADR parameter CBB.

Each client implementation that claims support for the Read, Write or InformationReport service shall be capable of supporting the VNAM and VADR parameter CBBs.

#### **. Named Variable Scope**

Each server implementation that claims support for the VNAM parameter CBB shall be capable of supporting either VMD-Specific or Domain-Specific named variables.

Each client implementation that claims support for the VNAM parameter CBB shall be capable of supporting both VMD-Specific and Domain-Specific named variables.

#### **. Address Types**

Each server implementation that claims support for the VADR parameter CBB shall be capable of supporting either the Symbolic-Address or Numeric-Address choice.

Each client implementation that claims support for the VADR parameter CBB shall be capable of supporting both the Symbolic-Address and Numeric-Address choices.

#### **. Semaphore Management**

Out of scope.

#### **. Operator Communication**

No additional requirements have been identified.

#### **. Event Management**

Out of scope.

#### **. Journal Management**

Out of scope.

#### **. File Access**

Out of scope.

**. File Management**

Out of scope.

**. Data Exchange Management**

Out of scope.



## **PART 2:**

# **Annex A - ISPICS Requirements List**

THIS PAGE IS INTENTIONALLY BLANK

## Annex A - ISPICS Requirements List

### A.. General

This annex describes the common MMS requirements in terms of tables which were derived from the base standard. They are intended to give a precise specification of requirements.

### A.. Classification of Requirements

Throughout this annex, to specify the level of support for each feature, the following classification is used.

**Client-CR** : Client Conformance Requirement.

**Server-CR** : Server Conformance Requirement

### A.. Base Column

The "Base" column reflects the definitions and specifications in ISO/IEC 9506-1:1990 and ISO/IEC 9506-2:1990. Each entry in this column is chosen from the following list:

**mandatory; m** : That feature shall be supported, i.e. its syntax and procedures shall be implemented as specified in the base standard.

However, it is not a requirement that the feature shall be used in all instances of communication, unless mandated by the base standard .

**optional; o** : Any feature denoted by "o" is left to the implementation as to whether that feature is implemented or not.

If a parameter is optionally supported, then the syntax shall be implemented, but it is left to each implementation whether the procedures are implemented or not.

### A.. F/S Column

The "F/S" column reflects the requirements of this Functional Standard. Each entry in this column is chosen from the following terminology:

**supported; m** : Any feature denoted by "m" is mandatory or optional in the base standard. That feature shall be supported, i.e. its syntax and procedures shall be implemented as specified in the base standard or in this ISP by all implementations claiming conformance to this ISP.

However, it is not a requirement that the feature shall be used in all instances of communication, unless mandated by the base standard or stated otherwise in this part of this A-Profile.

**optionally supported; o** : Any feature denoted by "o" is left to the implementation as to whether that feature is implemented or not.

If a parameter is optionally supported, then the syntax shall be implemented, but it is left to each implementation whether the procedures are implemented or not.

**conditionally supported; c** : Any feature denoted by "c<n>" shall be supported under the condition referenced c<n> specified in this ISP, where <n> stands for a number. If these conditions are not met, the feature is outside the scope of this ISP.

**excluded; x** : Any feature denoted by "x" is excluded in this ISP, i.e. an implementation shall behave as if the feature is not implemented.

**companion standard specific; cs** : Any feature denoted by "cs" is left to be defined by an ISP or a part of an ISP referencing this part, and based on a companion standard abstract syntax. For ISPs that are based on the abstract syntax defined by ISO/IEC 9506-2, "cs" is equivalent to "excluded; x".

**outside of scope; i** : Any feature denoted by "i" is outside the scope of this ISP, i.e. it may be ignored, and will therefore not be subject of an ISP conformance test. However the syntax of all parameters of supported PDUs shall be implemented, even if the procedures are not (i.e. the Receiver shall be able to decode the PDU).

**not applicable; -** : Any feature denoted by "-" is not defined in the context where it is mentioned, e.g. a parameter which is not part of the respective PDU. The occurrence of "not applicable" features is mainly due to the format of the tables in ISPICS Requirements List.

**functional standard choice; \*** : Any feature denoted by "\*" is left to be defined by an ISP or a part of an ISP referencing this part. The referencing profile shall replace the "\*" by any of the alternatives given in the list above.

## A.. Value/Reference

The "Value/Ref." column specifies constraints on values for the parameter and/or contains references to text in this or other documents.

## A.. Conditional MACROs

The following MACROs are used in the F/S Column:

**STR1** : Any feature denoted by "STR1" is conditioned on the support of STR1 Parameter CBB. Its requirement is left to be defined by an ISP that references this ISP and specifies the nature of its support for the STR1 Parameter CBB.

**STR2** : Any feature denoted by "STR2" is conditioned on the support of STR2 Parameter CBB. Its requirement is left to be defined by an ISP that references this ISP and specifies the nature of its support for the STR2 Parameter CBB.

**VADR** : Any feature denoted by "VADR" is conditioned on the support of VADR Parameter CBB. Its requirement is left to be defined by an ISP that references this ISP and specifies the nature of its support for the VADR Parameter CBB.

**VNAM** : Any feature denoted by "VNAM" is conditioned on the support of VNAM Parameter CBB. Its requirement is left to be defined by an ISP that references this ISP and specifies the nature of its support for the VNAM Parameter CBB.

**VLIS** : Any feature denoted by "VLIS" is conditioned on the support of VLIS Parameter CBB. Its requirement is left to be defined by an ISP that references this ISP and specifies the nature of its support for the VLIS Parameter CBB.

**VSCA** : Any feature denoted by "VSCA" is conditioned on the support of VSCA Parameter CBB. Its requirement is left to be defined by an ISP that references this ISP and specifies the nature of its support for the VSCA Parameter CBB.

**VALT** : Any feature denoted by "VALT" is conditioned on the support of VALT Parameter CBB. Its requirement is left to be defined by an ISP that references this ISP and specifies the nature of its support for the VALT Parameter CBB.

**REAL** : Any feature denoted by "REAL" is conditioned on the support of REAL Parameter CBB. Its requirement is left to be defined by an ISP that references this ISP and specifies the nature of its support for the REAL Parameter CBB.

**TPY** : Any feature denoted by "TPY" is conditioned on the support of TPY Parameter CBB. Its requirement is left to be defined by an ISP that references this ISP and specifies the nature of its support for the TPY Parameter CBB.

**MOD** : Any feature denoted by "MOD" is left to be defined by an ISP that references this ISP and specifies the nature of its support for the MMS Modifiers.

## **A.. Supported MMS PDU's**

**A.. Environment and General Management**

Ref	MMS PDU	Client-CR				Server-CR			
		Sending		Receiving		Sending		Receiving	
		Base	F/S	Base	F/S	Base	F/S	Base	F/S
1	InitiateRequest	o	*	o	*	o	*	m	m
2	InitiateResponse	o	*	o	*	m	m	o	*
3	InitiateError	o	*	o	*	m	m	o	*
4	ConcludeRequest	o	*	o	*	o	*	m	m
5	ConcludeResponse	o	*	o	*	m	m	o	*
6	ConcludeError	o	*	o	*	m	m	o	*
7	CancelRequest	o	*	o	*	o	*	o	*
8	CancelResponse	o	*	o	*	o	*	o	*
9	CancelError	o	*	o	*	o	*	o	*
10	Reject	m	m	m	m	m	m	m	m

Note: Abort service is provided by ACSE.

**A.. MMS Modifiers**

Ref	Modifier	Client-CR		Server-CR	
		Base	F/S	Base	F/S
1	attachToEventCondition	o	i	o	i
2	attachToSemaphore	o	i	o	i

**A.. Parameter CBBs**

Ref	Parameter	Base	Client-CR		Server-CR	
			F/S	Value/Ref.	F/S	Value/Ref.
1	str1	o	*		*	
2	str2	o	*		*	
3	vnam	o	c1		c1	
4	valt	o	*		*	
5	vadr	o	c1		c1	
6	vsca	o	x		x	
7	tpy	o	*		*	
8	vlis	o	*		*	
9	real	o	i		i	
10	cei	o	i		i	

c1: see section 5.2.5.4 to determine the requirements for these CBBs.

### A.. VMD Support

In this subclause and the following subclauses of A.3 the column "MMS PDU's" contains one single entry for each MMS service. In case of a confirmed service this single entry shall represent the corresponding Request-, Response- and Error-PDU'S. In case of an unconfirmed service it shall represent the corresponding Request-PDU.

For responder role service CBBs, the Client-CR column shall indicate the support of sending the Request-PDU and receiving the Response-PDU and Error-PDU, whereas, the Server-CR column shall indicate the support of receiving the Request-PDU and sending the Response-PDU and Error-PDU.

For requester role service CBBs, the Client-CR column shall indicate the support of receiving the Request-PDU and (in case of a confirmed service) sending the Response-PDU and Error-PDU, whereas, the Server-CR column shall indicate the support of sending the Request-PDU and (in case of a confirmed service) receiving the Response-PDU and Error-PDU.

NOTE - As an example, the 'm' in the Server-CR column for the Identify service means that the Server implementation has to support the receiving of the Identify-Request PDU and the sending of the Identify-Response PDU and the Identify-Error PDU, whereas the 'o' in the Client-CR column means that the Client implementation may or may not support the sending of the Identify-Request PDU, and the receiving of the Identify-Response PDU and the Identify-Error PDU.

Ref	MMS PDU	Client-CR		Server-CR	
		Base	F/S	Base	F/S
1	Status	o	*	o	*
2	UnsolicitedStatus	o	*	o	*
3	GetNameList	o	*	o	*
4	Identify	o	*	m	m
5	Rename	o	i	o	i
6	GetCapabilityList	o	*	o	*

### A.. Domain Management

Ref	MMS PDU	Client-CR		Server-CR	
		Base	F/S	Base	F/S
1	InitiateDownloadSequence	o	*	o	*
2	DownloadSegment	o	*	o	*
3	TerminateDownloadSequence	o	*	o	*
4	InitiateUploadSequence	o	*	o	*
5	UploadSegment	o	*	o	*

6	TerminateUploadSequence	o	*	o	*
7	RequestDomainDownload	o	*	o	*
8	RequestDomainUpload	o	*	o	*
9	LoadDomainContent	o	*	o	*
10	StoreDomainContent	o	*	o	*
11	DeleteDomain	o	*	o	*
12	GetDomainAttributes	o	*	o	*

### A.. Program Invocation Management

Ref	MMS PDU	Client-CR		Server-CR	
		Base	F/S	Base	F/S
1	CreateProgramInvocation	o	*	o	*
2	DeleteProgramInvocation	o	*	o	*
3	Start	o	*	o	*
4	Stop	o	*	o	*
5	Resume	o	*	o	*
6	Reset	o	*	o	*
7	Kill	o	*	o	*
8	GetProgramInvocationAttributes	o	*	o	*

### A.. Variable Access

Ref	MMS PDU	Client-CR		Server-CR	
		Base	F/S	Base	F/S
1	Read	o	*	o	*
2	Write	o	*	o	*
3	InformationReport	o	*	o	*
4	GetVariableAccessAttributes	o	*	o	*
5	DefineNamedVariable	o	c1	o	c1
6	DefineScatteredAccess	o	x	o	x
7	GetScatteredAccessAttributes	o	x	o	x
8	DeleteVariableAccess	o	c2	o	c2
9	DefineNamedVariableList	o	c3	o	c3
10	GetNamedVariableListAttributes	o	c3	o	c3
11	DeleteNamedVariableList	o	c3	o	c3
12	DefineNamedType	o	*	o	*



13	GetNamedTypeAttributes	o	*	o	*
14	DeleteNamedType	o	*	o	*

c1: to be defined by an ISP referencing this part. If this service is supported, then VNAM and VADR shall also be supported.

c2: to be defined by an ISP referencing this part. If this service is supported, then VNAM shall also be supported.

c3: to be defined by an ISP referencing this part. If this service is supported, then VLIS shall also be supported.

**A.. Semaphore Management**

Ref	MMS PDU	Client-CR		Server-CR	
		Base	F/S	Base	F/S
1	TakeControl	o	i	o	i
2	RelinquishControl	o	i	o	i
3	DefineSemaphore	o	i	o	i
4	DeleteSemaphore	o	i	o	i
5	ReportSemaphoreStatus	o	i	o	i
6	ReportPoolSemaphoreStatus	o	i	o	i
7	ReportSemaphoreEntryStatus	o	i	o	i

**A.. Operator Communication**

Ref	MMS PDU	Client-CR		Server-CR	
		Base	F/S	Base	F/S
1	Input	o	*	o	*
2	Output	o	*	o	*

**A.. Event Management**

Ref	MMS PDU	Client-CR		Server-CR	
		Base	F/S	Base	F/S
1	DefineEventCondition	o	i	o	i
2	DeleteEventCondition	o	i	o	i
3	GetEventConditionAttributes	o	i	o	i
4	ReportEventConditionStatus	o	i	o	i
5	AlterEventConditionMonitoring	o	i	o	i
6	TriggerEvent	o	i	o	i
7	DefineEventAction	o	i	o	i
8	DeleteEventAction	o	i	o	i
9	GetEventActionAttributes	o	i	o	i
10	ReportEventActionStatus	o	i	o	i
11	DefineEventEnrollment	o	i	o	i
12	DeleteEventEnrollment	o	i	o	i
13	GetEventEnrollmentAttributes	o	i	o	i
14	ReportEventEnrollmentStatus	o	i	o	i

15	AlterEventEnrollment	o	i	o	i
16	EventNotification	o	i	o	i
17	AcknowledgeEventNotification	o	i	o	i
18	GetAlarmSummary	o	i	o	i
19	GetAlarmEnrollmentSummary	o	i	o	i

### A.. Journal Management

Ref	MMS PDU	Client-CR		Server-CR	
		Base	F/S	Base	F/S
1	ReadJournal	o	i	o	i
2	WriteJournal	o	i	o	i
3	InitializeJournal	o	i	o	i
4	ReportJournalStatus	o	i	o	i
5	CreateJournal	o	i	o	i
6	DeleteJournal	o	i	o	i

### A.. File Access

Ref	MMS PDU	Client-CR		Server-CR	
		Base	F/S	Base	F/S
1	ObtainFile	o	i	o	i

### A.. File Management

This subclause is informative only.

Ref	MMS PDU	Client-CR		Server-CR	
		Base	F/S	Base	F/S
1	FileOpen	o	i	o	i
2	FileRead	o	i	o	i
3	FileClose	o	i	o	i

### A.. Data Exchange Management

Ref	MMS PDU	Client-CR	Server-CR
-----	---------	-----------	-----------

		Base	F/S	Base	F/S
1	GetDataExchangeAttributes	o	i	o	i
2	ExchangeData	o	i	o	i

## A. Additional PDUs

Ref	MMS PDU	Client-CR		Server-CR	
		Base	F/S	Base	F/S
1	Additional PDU	o	cs	o	cs

### A.. PDU-Specific Requirements

This clause contains tables for all PDUs which have been marked as 'm', '\*', or 'c<n>' in F/S column of clause A.3. Some of the PDU parameters represent complex structures which are described using the following conventions:

- If a parameter with label <x> is a CHOICE type, the corresponding alternatives are listed below this parameter, using the sub-labels <x>.a, <x>.b, <x>.c, etc.
- If a parameter with label <x> is a SEQUENCE or SEQUENCE OF SEQUENCE type, the sequence members are listed below that parameter using the sub-labels <x>.1, <x>.2, <x>.3, etc.
- Some of the complex parameters are described in separate tables. In these cases, parameter names start with an upper case letter, otherwise parameters start with a lower case letter.

### A.. Environment and General Management

#### A.. Initiate Request PDU

Ref	Parameter	Sending			Receiving		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	localDetailCalling	o	m	5.2.1.1.3	m	m	
2	proposedMaxServOutstandingCalled	m	m	5.2.1.1.2	m	m	
3	proposedMaxServOutstandingCalled	m	m	5.2.1.1.2	m	m	
4	proposedDataStructureNestingLevel	m	m		m	m	
5	initiateRequestDetail	m	m	Note 1	m	m	

Note 1: initiateRequestDetail is specified in ISO/IEC ISP 14226-3 or in another ISP referencing this part.

**A.. Initiate Response PDU**

Ref	Parameter	Sending			Receiving		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	localDetailCalled	o	m	5.2.1.1.4	m	m	
2	negotiatedMaxServOutstanding Calli	m	m	5.2.1.1.2	m	m	
3	negotiatedMaxServOutstanding Calle	m	m	5.2.1.1.2	m	m	
4	negotiatedDataStructureNesting Lev	m	m		m	m	
5	initiateResponseDetail	m	m	Note 1	m	m	

Note 1: initiateResponseDetail is specified in ISO/IEC ISP 14226-3 or in another ISP referencing this part.

**A.. Initiate Error PDU**

Ref	Parameter	Sending			Receiving		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	errorClass	m	m		m	m	
2	errorCode	m	m		m	m	
3	additionalCode	o	*		o	*	
4	additionalDescription	o	*		o	*	

**A.. Conclude Request PDU**

No parameter.

**A.. Conclude Response PDU**

No parameter.

**A.. Conclude Error PDU**

Ref	Parameter	Sending			Receiving		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	errorClass	m	m		m	m	
2	errorCode	m	m		m	m	

3	additionalCode	o	*		o	*	
4	additionalDescription	o	*		o	*	

**A.. Cancel Request PDU**

Ref	Parameter	Sending			Receiving		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	originalInvokeID	m	m		m	m	

**A.. Cancel Response PDU**

Ref	Parameter	Sending			Receiving		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	originalInvokeID	m	m		m	m	

**A.. Cancel Error PDU**

Ref	Parameter	Sending			Receiving		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	originalInvokeID	m	m		m	m	
2	errorClass	m	m		m	m	
3	errorCode	m	m		m	m	
4	additionalCode	o	*		o	*	
5	additionalDescription	o	*		o	*	

**A.. Reject PDU**

Ref	Parameter	Sending			Receiving		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	originalInvokeID	m	m		m	m	
2	rejectReason	m	m		m	m	

**A.. VMD Support****A.. Status Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	extendedDerivation	m	m		m	m	
4	csStatusRequest	o	CS		o	CS	

**A.. Status Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	vmdLogicalStatus	m	m		m	m	
3	vmdPhysicalStatus	m	m		m	m	
4	localDetail	o	m		o	*	
5	csStatusResponse	o	CS		o	CS	

**A.. Status Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

**A.. Unsolicited Status PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	vmdLogicalStatus	m	m		m	m	
2	vmdPhysicalStatus	m	m		m	m	
3	localDetail	o	m		o	*	
4	csStatusResponse	o	CS		o	CS	

**A.. GetNameList Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	objectClass	m	m		m	m	
4	csObjectClass	o	cs		o	cs	
5	objectScope	m	m		m	m	
6	continueAfter	m	m		m	m	
7	csGetNameListRequest	o	cs		o	cs	

**A.. GetNameList Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfIdentifier	m	m		m	m	
3	moreFollows	m	m		m	m	
4	csGetNameListResponse	o	cs		o	cs	

**A.. GetNameList Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

**A.. Identify Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.



1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	

**A.. Identify Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	vendorName	m	m		m	m	
3	modelName	m	m		m	m	
4	revision	m	m		m	m	
5	listOfAbstractSyntaxes	o	*		m	m	

**A.. Identify Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

**A.. GetCapabilityList Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	continueAfter	m	m		m	m	
4	csGetCapabilityListRequest	o	cs		o	cs	

**A.. GetCapabilityList Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfCapabilities	m	m		m	m	5.2.3.1
3	moreFollows	m	m		m	m	
4	csGetCapabilityListResponse	o	cs		o	cs	

#### A.4.2.13. GetCapabilityList Error PDU

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

### A.. Domain Management

#### A.. InitiateDownloadSequence Request PDU

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	domainName	m	m		m	m	
4	listOfCapabilities	m	m	5.2.3.1	m	m	
5	sharable	m	m		m	m	
6	csInitiateDownloadSequenceReq ues	o	cs		o	cs	

#### A.. InitiateDownloadSequence Response PDU

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	

2	csInitiateDownloadSequenceRes pon	o	cs		o	cs	
---	--------------------------------------	---	----	--	---	----	--

**A.. InitiateDownloadSequence Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

**A.. DownloadSegment Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	domainName	m	m		m	m	
4	csDownloadSegmentRequest	o	cs		o	cs	

**A.. DownloadSegment Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	loadData	m	m		m	m	
2.a	non-coded	o	m		o	*	
2.b	coded	o	*		o	*	
3	moreFollows	m	m		m	m	
4	csDownloadSegmentResponse	o	cs		o	cs	

**A.. DownloadSegment Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

### A.. TerminateDownloadSequence Request PDU

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	domainName	m	m		m	m	
4	discard	m	m		o	o	
4.1	errorClass	m	m		m	m	
4.2	errorCode	m	m		m	m	
4.3	additionalCode	o	*		o	*	
4.4	additionalDescription	o	*		o	*	
5	csTerminateDownloadSeqRequest	o	*		o	*	

### A.. TerminateDownloadSequence Response PDU

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	csTerminateDownloadSeqResponse	o	cs		o	cs	

### A.. TerminateDownloadSequence Error PDU

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	

2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

**A.. InitiateUploadSequence Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	domainName	m	m		m	m	
4	csInitiateUploadSequenceRequest	o	cs		o	cs	

**A.. InitiateUploadSequence Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	ulsmID	m	m		m	m	
3	listOfCapabilities	m	m		m	m	5.2.3.1
4	csInitiateUploadSequenceResponse	o	cs		o	cs	

**A.. InitiateUploadSequence Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

**A.. UploadSegment Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	ulsmID	m	m		m	m	
4	csUploadSegmentRequest	o	cs		o	cs	

**A.. UploadSegment Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	loadData	m	m		m	m	
2.a	non-coded	o	m		o	*	
2.b	coded	o	*		o	*	
3	moreFollows	m	m		m	m	
4	csUploadSegmentResponse	o	cs		o	cs	

**A.. UploadSegment Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

**A.. TerminateUploadSequence Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	

2	listOfModifier	o	MOD		o	MOD	
3	ulsmID	m	m		m	m	
4	csTerminateUploadSequenceReq ues	o	cs		o	cs	

**A.. TerminateUploadSequence Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	csTerminateUploadSeqResponse	o	cs		o	cs	

**A.. TerminateUploadSequence Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

**A.. RequestDomainDownload Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	domainName	m	m		m	m	
4	listOfCapabilities	m	m		o	*	5.2.3.1
5	sharable	m	m		m	m	
6	filename	m	m		m	m	
7	csRequestDomainDownloadReq uest	o	cs		o	cs	

**A.. RequestDomainDownload Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	csRequestDomainDownloadResponse	o	cs		o	cs	

**A.. RequestDomainDownload Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

**A.. RequestDomainUpload Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	domainName	m	m		m	m	
4	filename	m	m		m	m	
5	csRequestDomainUploadRequest	o	cs		o	cs	

**A.. RequestDomainUpload Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	csRequestDomainUploadResponse	o	cs		o	cs	



**A.. RequestDomainUpload Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

**A.. LoadDomainContent Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	domainName	m	m		m	m	
4	listOfCapabilities	o	*	5.2.3.1	m	m	
5	sharable	m	m		m	m	
6	filename	m	m		m	m	
7	thirdParty	o	TPY		o	TPY	
8	csLoadDomainContentRequest	o	CS		o	CS	

**A.. LoadDomainContent Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	csLoadDomainContentResponse	o	CS		o	CS	

**A.. LoadDomainContent Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.

1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

**A.. StoreDomainContent Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	domainName	m	m		m	m	
4	filename	m	m		m	m	
5	thirdParty	o	TPY		o	TPY	
6	csStoreDomainContentRequest	o	CS		o	CS	

**A.. StoreDomainContent Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	csStoreDomainContentResponse	o	CS		o	CS	

**A.. StoreDomainContent Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

**A.. DeleteDomain Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	domainName	m	m		m	m	
4	csDeleteDomainRequest	o	CS		o	CS	

**A.. DeleteDomain Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	csDeleteDomainResponse	o	CS		o	CS	

**A.. DeleteDomain Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

**A.. GetDomainAttributes Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	domainName	m	m		m	m	
4	csGetDomainAttributesRequest	o	CS		o	CS	

**A.. GetDomainAttributes Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfCapabilities	m	m		m	m	5.2.3.1
3	state	m	m		m	m	
4	mmsDeletable	m	m		m	m	
5	sharable	m	m		m	m	
6	listOfProgramInvocations	m	m		m	m	
7	uploadInProgress	m	m		m	m	
8	csGetDomainAttributesResponse	o	cs		o	cs	

**A.. GetDomainAttributes Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

**A.. Program Invocation Management****A.. CreateProgramInvocation Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	programInvocationName	m	m		m	m	
4	listOfDomainNames	m	m		m	m	
5	reusable	m	m		m	m	

6	monitorType	o	i		o	i	
7	csCreateProgramInvocationRequest	o	cs		o	cs	

**A.. CreateProgramInvocation Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	csCreateProgramInvocationResponse	o	cs		o	cs	

**A.. CreateProgramInvocation Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

**A.. DeleteProgramInvocation Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	programInvocationName	m	m		m	m	
4	csDeleteProgramInvocationRequest	o	cs		o	cs	

**A.. DeleteProgramInvocation Response PDU**

Ref	Parameter	Client-CR			Server-CR		
-----	-----------	-----------	--	--	-----------	--	--

		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	csDeleteProgramInvocationResponse	o	cs		o	cs	

**A.. DeleteProgramInvocation Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

**A.. Start Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	programInvocationName	m	m		m	m	
4	executionArgument	o	*		o	*	
4.a	simpleString	o	m		o	*	
4.b	encodedString	o	*		o	*	
5	csStartRequest	o	cs		o	cs	

**A.. Start Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	csStartResponse	o	cs		o	cs	

**A.. Start Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	
7	serviceSpecificInformation	m	m		m	m	5.2.4.1

**A.. Stop Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	programInvocationName	m	m		m	m	
4	csStopRequest	o	CS		o	CS	

**A.. Stop Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	csStopResponse	o	CS		o	CS	

**A.. Stop Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

7	serviceSpecificInformation	m	m		m	m	5.2.4.2
---	----------------------------	---	---	--	---	---	---------

**A.. Resume Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	programInvocationName	m	m		m	m	
4	executionArgument	o	*		o	*	
4.a	simpleString	o	m		o	*	
4.b	encodedString	o	*		o	*	
5	csResumeRequest	o	cs		o	cs	

**A.. Resume Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	csResumeResponse	o	cs		o	cs	

**A.. Resume Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	
7	serviceSpecificInformation	m	m		m	m	5.2.4.3

**A.. Reset Request PDU**



Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	programInvocationName	m	m		m	m	
4	csResetRequest	o	CS		o	CS	

**A.. Reset Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	csResetResponse	o	CS		o	CS	

**A.. Reset Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	
7	serviceSpecificInformation	m	m		m	m	5.2.4.4

**A.. Kill Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	programInvocationName	m	m		m	m	
4	csKillRequest	o	CS		o	CS	

**A.. Kill Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	csKillResponse	o	cs		o	cs	

**A.. Kill Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	
7	serviceSpecificInformation	m	m		m	m	5.2.4.5

**A.. GetProgramInvocationAttributes Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	programInvocationName	m	m		m	m	
4	csGetPIAttributesRequest	o	cs		o	cs	

**A.. GetProgramInvocationAttributes Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	State	m	m		m	m	
3	listOfDomainNames	m	m		m	m	
4	mmsDeletable	m	m		m	m	
5	reusable	m	m		m	m	

6	monitor	m	m		m	m	
7	executionArgument	m	m		m	m	
7.a	simpleString	o	m		o	*	
7.b	encodedString	o	*		o	*	
8	csGetPIAttributesResponse	o	cs		o	cs	

### A.. GetProgramInvocationAttributes Error PDU

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

### A.. Variable Access

#### A.. Read Request PDU

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	specificationWithResult	m	m		m	m	
4	VariableAccessSpecification	m	m		m	m	

#### A.. VariableAccessSpecification

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1.a	listOfVariable	o	m		m	m	
1.a.1	VariableSpecification	m	m		m	m	
1.a.2	AlternateAccess	o	VALT		o	VALT	
1.b	variableListName	o	VLIS		o	VLIS	

**A.. VariableSpecification**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1.a	name	o	VNAM		o	VNAM	
1.b	Address	o	VADR		o	VADR	
1.c	variableDescription	o	VADR		o	VADR	
1.c.1	Address	m	m		m	m	
1.c.2	TypeSpecification	m	m		m	m	
1.d	scatteredAccessDescription	o	VSCA		o	VSCA	
1.e	invalidated	m	m		m	m	

**A.. Address**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1.a	numericAddress	o	m		o	c1	
1.b	symbolicAddress	o	m		o	c1	
1.c	unconstrainedAddress	o	*		o	*	

c1: at least one of these address types must be supported (see section 5.2.5.6).

**A.. TypeSpecification**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1.a	typeName	o	*		o	*	
1.b	array	o	STR1		o	STR1	
1.b.1	packed	m	m		m	m	
1.b.2	numberOfElements	m	m		m	m	
1.b.3	TypeSpecification	m	m		m	m	
1.c	structure	o	STR2		o	STR2	
1.c.1	packed	m	m		m	m	
1.c.2	components	m	m		m	m	
1.c.2.1	componentName	o	VALT		o	VALT	
1.c.2.	TypeSpecification	m	m		m	m	
1.d	boolean	o	*		o	*	

1.e	bit-string	o	*		o	*	
1.f	integer	o	*		o	*	
1.g	unsigned	o	*		o	*	
1.h	floatingPoint	o	*		o	*	
1.i	real	o	REAL		o	REAL	
1.j	octet-string	o	*		o	*	
1.k	visible-string	o	*		o	*	
1.l	generalized-time	o	*		o	*	
1.m	binary-time	o	*		o	*	
1.n	bcd	o	*		o	*	
1.o	objId	o	*		o	*	

### A.. AlternateAccess

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1.a	unnamed	o	STR1		o	STR1	
1.a.1	selectAlternateAccess	m	m		m	m	
1.a.1.1	AccessSelection	m	m		m	m	
1.a.1.2	AlternateAccess	m	m		m	m	
1.a.2	SelectAccess	m	m		m	m	
1.b	named	o	STR2		o	STR2	
1.b.1	componentName	m	m		m	m	
1.b.2	AlternateAccessSelection	m	m		m	m	
1.b.2.1	selectAlternateAccess	o	m		m	m	
1.b.2.2	SelectAccess	o	m		m	m	

### A.. AccessSelection

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1.a	component	o	STR2		o	STR2	
1.b	index	o	STR1		o	STR1	
1.c	IndexRange	o	STR1		o	STR1	
1.d	allElements	o	STR1		o	STR1	

### A.. SelectAccess

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1.a	component	o	STR2		o	STR2	
1.b	index	o	STR1		o	STR1	
1.c	IndexRange	o	STR1		o	STR1	
1.d	allElements	o	STR1		o	STR1	

### A.. IndexRange

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	lowIndex	m	m		m	m	
2	numberOfElements	m	m		m	m	

### A.. Read Response PDU

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokelD	m	m		m	m	
2	VariableAccessSpecification	m	m	A.4.5.1.1.	m	m	
3	listOfAccessResult	m	m		m	m	
3.a	failure	m	m		m	m	
3.b	Data	m	m		m	m	

### A.. Data

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
a	array	o	STR1		o	STR1	
b	structure	o	STR2		o	STR2	
c	boolean	o	*		o	*	
d	bit-string	o	*		o	*	
e	integer	o	*		o	*	
f	unsigned	o	*		o	*	
g	floating-point	o	*		o	*	

h	real	o	REAL		o	REAL	
i	octet-string	o	*		o	*	
j	visible-string	o	*		o	*	
k	generalized-time	o	*		o	*	
l	binary-time	o	*		o	*	
m	bcd	o	*		o	*	
n	booleanArray	o	*		o	*	
o	objectId	o	*		o	*	

**A.. Read Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

**A.. Write Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	VariableAccessSpecification	m	m	A.4.5.1.1.	m	m	
4	listOfData	m	m	A.4.5.2.1.	m	m	

**A.. Write Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfWriteResult	m	m		m	m	
2.a	dataAccessError	m	m		m	m	

2.b	success	m	m		m	m	
-----	---------	---	---	--	---	---	--

**A.. Write Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

**A.. InformationReport PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	VariableAccessSpecification	m	m	A.4.5.1.1.	m	m	
2	listOfAccessResult	m	m	A.4.5.2.1.	m	m	
2.a	failure	m	m		m	m	
2.b	Data	m	m		m	m	

**A.. GetVariableAccessAttributes Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	variableName	o	VNAM		o	VNAM	
4	variableAddress	o	VADR		o	VADR	

**A.. GetVariableAccessAttributes Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.



1	invokeID	m	m		m	m	
2	mmsDeletable	m	m		m	m	
3	Address	o	VADR		o	VADR	
4	TypeSpecification	m	m		m	m	

**A.. GetVariableAccessAttributes Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

**A.. DefineNamedVariable Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	variableName	m	m		m	m	
4	Address	m	m	A.4.5.1.3.	m	m	
5	TypeSpecification	o	o	A.4.5.1.4.	m	m	

**A.. DefineNamedVariable Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	

**A.. DefineNamedVariable Error PDU**

Ref	Parameter	Client-CR			Server-CR		
-----	-----------	-----------	--	--	-----------	--	--

		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

**A.. DeleteVariableAccess Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	scopeOfDelete	m	m		m	m	
4	listOfName	o	o		m	m	
5	domainName	o	o		m	m	

**A.. DeleteVariableAccess Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	numberMatched	m	m		m	m	
3	numberDeleted	m	m		m	m	

**A.. DeleteVariableAccess Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

7	numberDeleted	m	m		m	m	
---	---------------	---	---	--	---	---	--

**A.. DefineNamedVariableList Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	variableListName	m	m		m	m	
4	listOfVariable	m	m	A.4.5.1.1.	m	m	
4.1	VariableSpecification	m	m		m	m	
4.2	AlternateAccess	o	VALT		o	VALT	

**A.. DefineNamedVariableList Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	

**A. DefineNamedVariableList Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

**A.. GetNamedVariableListAttributes Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	

2	listOfModifier	o	MOD		o	MOD	
3	variableListName	m	m		m	m	

**A.. GetNamedVariableListAttributes Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	mmsDeletable	m	m		m	m	
3	listOfVariable	m	m		m	m	
3.1	VariableSpecification	m	m		m	m	
3.2	AlternateAccess	o	VALT		o	VALT	

**A.. GetNamedVariableListAttributes Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

**A.. DeleteNamedVariableList Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	scopeOfDelete	m	m		m	m	
4	listOfVariableListName	o	o		m	m	
5	domainName	o	o		m	m	

**A.. DeleteNamedVariableList Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	numberMatched	m	m		m	m	
3	numberDeleted	m	m		m	m	

**A.. DeleteNamedVariableList Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	
7	numberDeleted	m	m		m	m	

**A.. DefineNamedType Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	typeName	m	m		m	m	
4	TypeSpecification	m	m		m	m	

**A.. DefineNamedType Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	

**A.. DefineNamedType Error PDU**

Ref	Parameter	Server-CR			Client-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

### A.. GetNamedTypeAttributes Request PDU

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	typeName	m	m		m	m	

### A.. GetNamedTypeAttributes Response PDU

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	mmsDeletable	m	m		m	m	
3	TypeSpecification	m	m		m	m	

### A.. GetNamedTypeAttributes Error PDU

Ref	Parameter	Server-CR			Client-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

**A.. DeleteNamedType Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	scopeOfDelete	m	m		m	m	
4	listOfTypeName	o	o		m	m	
5	domainName	o	o		m	m	

**A.. DeleteNamedType Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	numberMatched	m	m		m	m	
3	numberDeleted	m	m		m	m	

**A.. DeleteNamedType Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	
7	numberDeleted	m	m		m	m	

**A.. Semaphore Management**

Out of Scope.

**A.. Operator Communication**

**A.. Input Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	listOfModifier	o	MOD		o	MOD	
3	operatorStationName	m	m		m	m	
4	echo	m	m		m	m	
5	listOfPromptData	o	*		o	*	
6	inputTimeOut	o	*		o	*	
7	csInputRequest	o	cs		o	cs	

**A.. Input Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	inputString	m	m		m	m	
3	csInputResponse	o	cs		o	cs	

**A.. Input Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

**A.. Output Request PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	



2	listOfModifier	o	MOD		o	MOD	
3	operatorStationName	m	m		m	m	
4	listOfOutputData	m	m		m	m	
5	csOutputRequest	o	cs		o	cs	

**A.. Output Response PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	csOutputResponse	o	cs		o	cs	

**A.. Output Error PDU**

Ref	Parameter	Client-CR			Server-CR		
		Base	F/S	Value/Ref.	Base	F/S	Value/Ref.
1	invokeID	m	m		m	m	
2	modifierPosition	o	MOD		o	MOD	
3	errorClass	m	m		m	m	
4	errorCode	m	m		m	m	
5	additionalCode	o	*		o	*	
6	additionalDescription	o	*		o	*	

**A.. Event Management**

Out of Scope

**A.. Journal Management**

Out of Scope

**A.. File Access**

Out of Scope

**A.. File Management**

Out of Scope

**A.. Data Exchange Management**

Out of Scope