

Speech

WAVE is capable of 'Speaking' the current frequency and/or time. This option is activated from the Speech option on the Chron menu.

If your computer is not equipped with the appropriate Hardware or Software (see Requirements Chapter) the Speech menu item will be dimmed and thus is not available.

An example of the use of the Speech function is diagrammed below:

In this case, the Stereo Tape Recorder is used to record the Radio Audio on one channel of the tape and the Sound out of the Macintosh on the other channel. With WAVE running and controlling the Tape Recorder (Tape -> Track Delay) and Speech enabled (your choice of information), the recorder will be started at the onset of a contact and

the Macintosh will announce the chosen information on one channel while the radio traffic will be recorded on the other channel. When playing the tape back, the balance control on the playback unit can be used to isolate the two different channels.

As you can see, this feature, along with a Chronology Log, can give you an exact indication of events that occurred during monitoring.