

Summary

The floppy disk(s) could not be accessed. The error indicates a hardware problem.

Details

The main circuit board of your Mac contains circuitry called an IWM (Integrated Woz Machine) - named after the inventor: Steve Wozniak. The IWM provides access to and control of the floppy disk or disks on your system. That circuitry has failed.

What to do

You will have to replace the entire main circuit board of your computer to fix this problem.