Appendix.

Recommended upgrade paths

System upgrading from	Recommended upgrade to	Comments
Series 3x, II, III	Series 917LX, 927LX, 937LX	Box swap
All MICRO 3000s	Series 917LX, 927LX, 937LX	Box swap
		·
Series 39, 40, 42, 44, 48	Series 927LX,937LX, 937, 947LX	Box swap
Series 42XP, 52, 58	Series 937LX, 937, 947LX, 947	Box swap
Series 64, 68	Series 937LX, 937, 947LX, 947, 957	Box swap
Series 70	Series 937LX, 937, 947LX, 947, 957LX, 957, 967	Box swap
Series 925LX	Series 937LX, 937, 947LX, 947	Box swap
Series 925	Series 937, 947	Box swap
Series 935	Series 947, 957	Box swap
Series 949	Series 967, 987	Box swap
		r
Series 920	Series 922LX, 922RX, 937LX, 937	Board upgrade, box swap
Series 922LX	Series 922RX, 922, 932, 937LX, 937, 947LX, 947	Board upgrade, box swap
Series 922RX	Series 922, 932, 937, 947	Board upgrade, box swap
Series 922	Series 932, 937, 947	Board upgrade, box swap
Series 932	Series 948, 947, 957	Board upgrade, box swap
Series 948	Series 958, 957, 967, 987	Board upgrade, box swap
Series 958	Series 987, CS 992/100	Box swap
Series 917LX	Series 927LX, 937LX	Board upgrade
Series 927LX	Series 937LX, 947LX	Board upgrade
Series 937LX	Series 937, 947LX, 947	Package/board upgrade
Series 937	Series 947	Board upgrade
Series 947LX	Series 947, 957	Package/board upgrade
Series 947	Series 957	Board upgrade
Series 957LX	Series 957, 967	Package/board upgrade
Series 957	Series 967	Board upgrade
Series 967LX	Series 967	Package/board upgrade
Series 977	Series 987	Board upgrade
Series 987	Series 987/150	Board upgrade
Series 950	Series 947, 957, 967, 987	Box swap
Series 955	CS 990, Series 967, 987	Box swap
Series 960	CS 990, CS992/100, Series 967, 987, 987/150	Box swap
Series 980/100	CS 992/100	Box swap
Series 980/200	CS 992/200	Box swap
Series 980/300	CS 992/200	Box swap
Series 980/400	CS 992/400	Box swap
301100 300/ 700	00 00H 100	DON OTTUP

NOTE:

937 = 937RX,SX

947 = 947RX,SX

957 = 957RX,SX

967 = 967RX,SX

987 = 987RX, RX, 987/150