

HP ScanJet Scanners Properties

By choosing the HP ScanJet Scanners Properties option, you can view and change the default scanner, test the scanner and view the SCSI card to which it is connected. This help system is for Windows 95 and Windows NT. The SCSI entry does not apply to Windows NT systems. To get help , click on any underlined topic.

General

Test

SCSI

General

This dialog box is where you can view and change the default scanner. You can also get detailed information about the default scanner. To get help, click any underlined topic.

Default Scanner

Current Scanner

Make Default button

Info button

OK button

Cancel button

Test

This dialog box lets you test the installation of the scanner and some optional accessories. To get help, click on any underlined topic.

Scanner button

ADF button

/T button

OK button

Cancel button

SCSI

This dialog box displays the SCSI card installed in your computer and displays available SCSI addresses. To get help, click on any underlined topic.

SCSI Card

Available SCSI Addresses

OK button

Cancel button

Displays the scanner you have selected as the default scanner. This scanner remains the default scanner until you select a new one from the Current Scanner list and then click on the Make Default button.

Lets you select a scanner from the ones that are connected to your computer. Click on the arrow to display the complete list of scanners.

Makes the current scanner the default scanner.

Displays information such as the product code for your HP ScanJet Scanners. You may need this information if you are troubleshooting problems with your scanner.

Closes the dialog box and saves any changes you have made.

Closes the dialog box without saving any changes you have made.

Tests for the correct installation of the current scanner. If you get an error, follow the directions in the message and then refer to the *Installation Guide* for the HP ScanJet Scanners.

Tests for the correct installation of the Automatic Document Feeder (ADF). If you get an error, follow the directions in the message and then refer to the *Automatic Document Feeder User's Guide*.

Tests for the correct installation of the optional adapter for scanning transparencies. If you get an error, follow the directions in the message and then refer to the guide that comes with the transparency adapter for HP ScanJet Scanners.

Selects the SCSI (small computer system interface) card that you want to view free addresses for. For more information, see the *Installation Guide* for the HP ScanJet Scanners.

Lists all SCSI addresses that are available for use on the selected SCSI card. Remember the number of one of these empty addresses so that you can set the SCSI address switch on your scanner to that address. For more information, see the *Installation Guide* for the HP ScanJet Scanners.

