

Click this button to display advanced settings for 3Dfx Voodoo Banshee hardware and software drivers.

Click this button to display settings for viewing output on a TV.

Click this button to select refresh rates for specific video modes.

Click this button to reset all Gamma values to the last saved values.

Click this button to display hardware and driver information.

Click this button to reset all Gamma values to factory default values.

Tab control (Desktop/Glide/D3D)

Check this box to link the Red, Green and Blue Gamma dials together so the same value can be used.

Use this control to adjust the amount of Red Gamma.

Use this control to adjust the amount of Green Gamma.

Use this control to adjust the amount of Blue Gamma.

Red gamma value

Green gamma value

Blue gamma value

When selected, Glide applications will force 2 Mbytes of texture memory for the texture mapping unit. Some Glide games may not work correctly if this option is not selected.

When selected, Glide will enable triple color buffering if there is enough frame buffer memory to support it. Rendering performance may increase when selected, however not all applications are compatible with triple color buffering, and some may exhibit visual artifacts.

When selected, buffer swaps will not be synchronized with the vertical retrace signal of the monitor. Rendering performance may increase when selected, however visual tearing may occur.

When selected, use higher quality video filtering. This may impact performance.

When selected, the Glide splash screen will not be shown.

When selected, texture mipmap dithering will be enabled. Visual quality may improve when selected, however a decrease in rendering performance may occur.

When selected, Direct3D will force on anti-aliasing. Visual quality may look much smoother when selected, with little or no decrease in performance.

When selected, overlay mode is enabled.

Set gamma controls and advanced features for Direct3D applications.

Set gamma controls and advanced features for Glide applications.

Set gamma controls for your desktop.

Click this button to set all Direct3D advanced features to factory defaults.

Click this button to set all Glide advanced features to factory defaults.

Check this box to enable output to a TV.

Check this box to disable output to an analog monitor, provided the TV output is currently active.

Check this box to switch your TV signal type between NTSC and PAL.

3Dfx Splash Screen

Choose the type of setting you want to change, then adjust it with the slider below.

Adjust TV properties.

Move the TV picture up.

Move the TV picture down.

Move the TV picture to the left.

Move the TV picture to the right.

