Newton Error Codes

The Newton, a hand held Personal Digital Assistant (PDA) by Apple Computer and Sony, is a truly remarkable machine (at least to those of us who don't have one and can only dream...), but unfortunetly not immune to errors. The good news is, it doesn't have that many, yet.

They way I've listed the Newton errors is a bit less straight forward then the Mac system errors because I'm not sure of the way they show up on the Newton. I do know the format so there shouldn't be too many problems (I hope!).

An example of a Newton error would be -48002, which is 'store format is too old to understand'. Ignore the -4, as far as I know it currenly has no meaning except to be there. The '80' part of the number is the error type, which would be 'Store Errors'. These are listed in the 'Error Type' section. The '002' is the error number which specifically identifies what the error is. These are listed in the 'Error Number' section. Put the two together and your on a roll...

If there are any I'm missing please e-mail me (see Freeware Notice) and I'll include it in the next release. Thanks.

Error Type

80 Store Error 82 Object System Error 84 Bad Type Error 88 Interpreter Error

Error Number

2

store format is too old to understand 3

store format is too new to understand4 store is corrupted, cannot recover5

single object is corrupted, cannot recover 9

not a soup entry

10

tried to remove a store that was not registered 11

soup index has an unknown type 12

soup index has an unknown key structure 13

soup index does not exist 14

a soup with this name already exists 15

tried to CopyEntries to an unknown soup 16

soup is invalid 17

soup is invalid 18

entry is invalid 19

key does not have the type specified in the index $\mathbf{20}$

store is in ROM 21

soup already has an index with this path 22

internal error 23

tried to call RemoveIndex on the _uniqueID index 24

queary type missing or unknown 25

discovered index inconsistency 200 expected frame, array, or binary object, but got something else 202 empty path 203 invalid segment in path 204 path failed 205 index out of bounds (string or array) 206 source and destination must be different objects 207 long out of range (too large or small) 210 bad arguments 211 string too big 214 object is read-only 215 functionality is unimplemented 400 expected a frame 401 expected an array 402 expected a string 403 expected a pointer 404 expected a number 405 expected a real 406 expected an integer 407 expected a character 408 expected a binary object 409 expected a path expression, symbol or integer 410 expected a symbol 411 expected a symbol 412 expected a fram or an array 413 expected an array or NIL 414 expected a string or NIL 415 expected a binary object or NIL 416 unexpected frame 417 unexpected binary object 418

unexpected immediate 499 unexpected Spanish Inquisition 800 not in a break loop, but presumably called break 802 too many arguments for a CFunction 803 wrong number of arguments 804 FOR loop BY expression has value zero 806 no current exception 807 undefined variable 808 undefined global function 809 undefined method 810 no _proto for inherited send 811 tried to access slot in NIL context 814 local variables and FOR/WITH loops are not

allowed at top level